

Wall-hung gas condensing boilers

## MCA 15 - MCA 25 MCA 25/28 MI



### Installation and Service Manual

# Declaration of conformity

The appliance complies with the standard model described in declaration of compliance **CE**. It is manufactured and distributed pursuant to the requirements of european directives.

The original of the declaration of compliance is available from the manufacturer.

**EG - VERKLARING VAN OVEREENSTEMMING  
EC - DECLARATION OF CONFORMITY  
EG - KONFORMITÄTSERKLÄRUNG  
DÉCLARATION DE CONFORMITÉ CE**

Fabrikant/Manufacturer/Hersteller/Fabricant : Remeha B.V.  
Adres/Address/Adresse : Kanaal Zuid 110  
Stad, Land/City, Country/Land, Ort/Ville, pays : Postbus 32, NL-7300 AA Apeldoorn

verklaart hiermede dat de toestel(len) : MCA ../.. (MI) (BIC)  
this is to declare that the following product(s) :  
erklärt hiermit das die Produk(te) :  
déclare ici que les produit(s) suivant(s) :

op de markt gebracht door : De Dietrich Thermique  
distributeur : 57, rue de la Gare, F-67580  
Vertreiber :  
Commercialisé (s) par :

voldoet/voldoen aan de bepalingen van de onderstaande EEG-richtlijnen:  
is/are in conformity with the following EEC-directives:  
den Bestimmungen der nachfolgenden EG-Richtlinien entspricht/entsprechen:  
répond/répondent aux directives CEE suivantes:

EEG-Richtlijn:	90/396/EEG	toegepaste normen:	
EEC-Directive:	90/396/EEC	tested and examined to the following norms:	
EG-Richtlinie:	90/396/EWG	verwendete Normen, normes appliquées:	
CEE-Directive:	90/396/CEE	EN 297(1994*), 483(1999*), 677(1998*)	
	92/42/EEG		
	92/42/EEC		
	92/42/EWG		
	92/42/CEE		
	2006/95/EEG	EN 50165(1997*), EN 60335-1(1994*)	<b>CE</b> 08
	2006/95/EEC	EN 60335-2-102(2004*)	
	2006/95/EWG		
	2006/95/CEE		
	2004/108/EEG	EN 50165(1997*)	
	2004/108/EEC	EN 55014-2(1997*), EN 55014-1(2000*),	
	2004/108/EWG	EN 61000-3-2(2000*), 61000-3-3(1995*)	
	2004/108/CEE		
	97/23/EEG	(art. 3, lid 3)	
	97/23/EEC	(article 3, sub 3)	
	97/23/EWG	(Art. 3, Absatz 3)	
	97/23/CEE	(art.3 section 3)	

\*) inclusief (eventuele) aanvulling, including (if any) completion  
einschließlich (falls vorhanden) Vervollständigung, y compris (le cas échéant) complément

Apeldoorn, decembre 2009



W.F. Tjihuis  
Approval manager  
703/2009/12/28

# Contents

---

<b>1</b>	<b>Introduction .....</b>	<b>6</b>
	<b>1.1 Used symbols .....</b>	<b>6</b>
	<b>1.2 Abbreviations .....</b>	<b>6</b>
	<b>1.3 General .....</b>	<b>7</b>
	1.3.1 Manufacturer's liability .....	7
	1.3.2 Installer's liability .....	7
	<b>1.4 Homologations .....</b>	<b>7</b>
	1.4.1 Certifications .....	7
	1.4.2 Gas categories .....	8
	1.4.3 Additional Directives .....	8
	1.4.4 Factory test .....	8
<b>2</b>	<b>Safety instructions and recommendations .....</b>	<b>9</b>
	<b>2.1 Safety instructions .....</b>	<b>9</b>
	<b>2.2 Recommendations .....</b>	<b>9</b>
<b>3</b>	<b>Technical description .....</b>	<b>11</b>
	<b>3.1 General description .....</b>	<b>11</b>
	<b>3.2 Main parts .....</b>	<b>11</b>
	<b>3.3 Operating principle .....</b>	<b>12</b>
	3.3.1 Skeleton Diagrams .....	12
	3.3.2 Shunt pump .....	12
	3.3.3 Water flow rate .....	13
	<b>3.4 Technical characteristics .....</b>	<b>13</b>
	3.4.1 Sensor characteristics .....	14
<b>4</b>	<b>Installation .....</b>	<b>16</b>
	<b>4.1 Regulations governing installation .....</b>	<b>16</b>
	<b>4.2 Package list .....</b>	<b>16</b>
	4.2.1 Standard delivery .....	16
	4.2.2 Accessories .....	16
	<b>4.3 Choice of the location .....</b>	<b>17</b>
	4.3.1 Data plate .....	17
	4.3.2 Location of the appliance .....	18
	4.3.3 Ventilation .....	18
	4.3.4 Main dimensions .....	19

<b>4.4</b>	<b>Installing the mounting frame .....</b>	<b>20</b>
<b>4.5</b>	<b>Positioning the boiler .....</b>	<b>21</b>
<b>4.6</b>	<b>Hydraulic connections .....</b>	<b>22</b>
4.6.1	Flushing the system .....	22
4.6.2	Connection of the heating circuit .....	22
4.6.3	Hydraulic connection of the water circuit for domestic use .....	23
4.6.4	Connecting the expansion vessel .....	23
4.6.5	Connecting the condensate discharge pipe .....	24
4.6.6	Filling the siphon .....	24
<b>4.7</b>	<b>Gas connection .....</b>	<b>25</b>
<b>4.8</b>	<b>Flue gas system connections .....</b>	<b>26</b>
4.8.1	Classification .....	26
4.8.2	Lengths of the air/flue gas pipes .....	27
<b>4.9</b>	<b>Installing the outside sensor .....</b>	<b>28</b>
4.9.1	Choice of the location .....	28
4.9.2	Installing the outside sensor .....	28
<b>4.10</b>	<b>Electrical connections .....</b>	<b>29</b>
4.10.1	Control unit .....	29
4.10.2	Recommendations .....	30
4.10.3	Position of the PCBs .....	31
4.10.4	Accessing the connection terminal blocks .....	32
4.10.5	Connecting a direct heating circuit .....	34
4.10.6	Connecting a direct heating circuit and a domestic hot water tank .....	35
4.10.7	Connecting two circuits and a domestic hot water tank before the mixing tank .....	37
4.10.8	Connecting two circuits and a domestic hot water tank after the mixing tank .....	39
4.10.9	Hot water storage tank connection .....	41
4.10.10	Pool connection .....	46
4.10.11	Connecting a mixed tank .....	48
4.10.12	Connecting the options .....	49
4.10.13	Connection in cascade .....	50
<b>4.11</b>	<b>Electrical diagram .....</b>	<b>53</b>
<b>4.12</b>	<b>Filling the system .....</b>	<b>54</b>
4.12.1	Water treatment .....	54
4.12.2	Filling the system .....	56
<b>5</b>	<b>Start-up .....</b>	<b>57</b>
<b>5.1</b>	<b>Control panel .....</b>	<b>57</b>
5.1.1	Description of the keys .....	57
5.1.2	Description of the display .....	58
5.1.3	Access to the various browsing levels .....	60
5.1.4	Browsing in the menus .....	62
<b>5.2</b>	<b>Check points before commissioning .....</b>	<b>63</b>
5.2.1	Preparing the boiler for commissioning .....	63

5.2.2	Gas circuit .....	64
5.2.3	Hydraulic circuit .....	64
5.2.4	Electrical connections .....	64
<b>5.3</b>	<b>Putting the appliance into operation .....</b>	<b>65</b>
<b>5.4</b>	<b>Gas settings .....</b>	<b>66</b>
5.4.1	Adapting to another gas type .....	66
5.4.2	Setting the air/gas ratio (Full load) .....	67
5.4.3	Setting the air/gas ratio (Part load) .....	69
5.4.4	Basic setting for the gas/air ratio .....	71
<b>5.5</b>	<b>Checks and adjustments after commissioning .....</b>	<b>71</b>
5.5.1	Displaying the parameters in extended mode .....	71
5.5.2	Setting the parameters specific to the installation .....	72
5.5.3	Naming the circuits and generators .....	75
5.5.4	Setting the heating curve .....	76
5.5.5	Finalizing work .....	78
<b>5.6</b>	<b>Reading out measured values .....</b>	<b>78</b>
<b>5.7</b>	<b>Changing the settings .....</b>	<b>79</b>
5.7.1	Language selection .....	80
5.7.2	Calibrating the sensors .....	80
5.7.3	"Professional" settings .....	82
5.7.4	Configuring the network .....	88
5.7.5	Returning to the factory settings .....	96
<b>6</b>	<b>Switching off the appliance .....</b>	<b>97</b>
6.1	Installation shutdown .....	97
6.2	Frost protection .....	97
<b>7</b>	<b>Checking and maintenance .....</b>	<b>98</b>
7.1	General instructions .....	98
7.2	Chimney sweep instructions .....	98
7.3	Customising maintenance .....	99
7.3.1	Maintenance message .....	99
7.3.2	Installer's contact details .....	100
7.4	Standard inspection and maintenance operations .....	100
7.4.1	Checking the hydraulic pressure .....	101
7.4.2	Checking the opened expansion vessel .....	101
7.4.3	Checking the ionisation current .....	101
7.4.4	Checking the transfer capacity .....	101
7.4.5	Checking the tightness of the combusted gases evacuation and air inlet connections .....	101
7.4.6	Checking combustion .....	102
7.4.7	Checking the automatic air vent .....	103

7.4.8	Checking the safety valve .....	104
7.4.9	Checking the siphon .....	104
7.4.10	Checking the burner and cleaning the heat exchanger .....	105
<b>7.5</b>	<b>Specific maintenance operations .....</b>	<b>106</b>
7.5.1	Replacing the ionisation/ignition electrode .....	106
7.5.2	Cleaning the plate exchanger (domestic hot water end) and the water filter cartridge .....	106
7.5.3	Replacing the 3-way valve .....	109
7.5.4	Replacing the non-return valve .....	110
7.5.5	Assembling the boiler .....	111
<b>8</b>	<b>Troubleshooting .....</b>	<b>112</b>
8.1	Messages (Code type Bxx or Mxx) .....	112
8.2	Message history .....	114
8.3	Faults (Code type Lxx or Dxx) .....	115
8.3.1	Deletion of sensors from the memory in the PCB .....	123
8.3.2	Deleting the IOBL 3WV modules from the memory in the PCB .....	123
8.4	Failure history .....	124
8.5	Parameter and input/output check (mode tests) .....	125
<b>9</b>	<b>Spare parts .....</b>	<b>129</b>
9.1	General .....	129
9.2	Spare parts .....	129
9.2.1	Casing .....	130
9.2.2	Heat exchanger and burner .....	131
9.2.3	Fan .....	132
9.2.4	Control panel .....	133
9.2.5	Connecting pipes (MCA 15 - MCA 25) .....	134
9.2.6	Connecting pipes (MCA 25/28 MI) .....	135
9.2.7	Spare parts list .....	136



# 1 Introduction

---

## 1.1 Used symbols

---

In these instructions, various danger levels are employed to draw the user's attention to particular information. In so doing, we wish to safeguard the user's safety, obviate hazards and guarantee correct operation of the appliance.



### DANGER

Risk of a dangerous situation causing serious physical injury.



### WARNING

Risk of a dangerous situation causing slight physical injury.



### CAUTION

Risk of material damage.



Signals important information.



Signals a referral to other instructions or other pages in the instructions.

## 1.2 Abbreviations

---

- ▶ **3CE**: Collective conduit for sealed boiler
- ▶ **DHW**: Domestic hot water
- ▶ **Interscenario switch**: Home automation switch that can be used to centralise and control several scenarios
- ▶ **Hi**: Lower heating value LHV
- ▶ **Hs**: Higher heating value HHV
- ▶ **IOBL**: Carrier current home automation bus
- ▶ **PPS**: Polypropylene hardly inflammable
- ▶ **PCU**: Primary Control Unit - PCB for managing burner operation
- ▶ **PSU**: Parameter Storage Unit - Parameter storage for PCBs PCU and SU
- ▶ **SCU**: Secondary Control Unit - **Diematic iSystem** control panel PCB
- ▶ **SU**: Safety Unit - Safety PCB
- ▶ **3WV**: 3-way valve



## 1.3 General

---

### 1.3.1. Manufacturer's liability

---

Our products are manufactured in compliance with the requirements of the various european applicable Directives. They are therefore delivered with **CE** marking and all relevant documentation.

In the interest of customers, we are continuously endeavouring to make improvements in product quality. All the specifications stated in this document are therefore subject to change without notice.

Our liability as the manufacturer may not be invoked in the following cases:

- ▶ Failure to abide by the instructions on using the appliance.
- ▶ Faulty or insufficient maintenance of the appliance.
- ▶ Failure to abide by the instructions on installing the appliance.

### 1.3.2. Installer's liability

---

The installer is responsible for the installation and initial start up of the appliance. The installer must respect the following instructions:

- ▶ Read and follow the instructions given in the manuals provided with the appliance.
- ▶ Carry out installation in compliance with the prevailing legislation and standards.
- ▶ Perform the initial start up and carry out any checks necessary.
- ▶ Explain the installation to the user.
- ▶ Warn the user of the obligation to check the appliance and maintain it in good working order.
- ▶ Give all the instruction manuals to the user.

## 1.4 Homologations

---

### 1.4.1. Certifications

---


CE identification no	<b>PIN 0063BT3444</b>
NOx classification	<b>5 (EN 297 pr A3, EN 656)</b>
Type of connection	Chimney: B <sub>23</sub> , B <sub>33</sub> Flue gas outlet: C <sub>13</sub> , C <sub>33</sub> , C <sub>43</sub> , C <sub>53</sub> , C <sub>63</sub> , C <sub>83</sub> , C <sub>93</sub>

## 1.4.2. Gas categories

---

Gas category	Gas type	Connection pressure (mbar)
I <sub>2</sub> ESi3P	Natural gas H (G20)	20
	Natural gas L (G25)	25
	Propane (G31)	37

The boiler is preset in the factory to operate on natural gas H (G20).

 For operation on another type of gas, see chapter: "Adapting to another gas type", page 66.

## 1.4.3. Additional Directives

---

Apart from the legal provisions and Directives, the additional Directives described in these instructions must also be observed.

For all provisions and Directives referred to in these instructions, it is agreed that all addenda or subsequent provisions will apply at the time of installation.



### WARNING

Installation of the appliance must be done by a qualified engineer in accordance with prevailing local and national regulations.

## 1.4.4. Factory test

---

Before leaving the factory, each boiler is set for optimum performance and tested to check the following items:

- ▶ Electrical safety
- ▶ Adjustment (CO<sub>2</sub>)
- ▶ Domestic hot water mode (Only on models with domestic hot water production)
- ▶ Water tightness
- ▶ Gas tightness
- ▶ Parameter settings

## 2 Safety instructions and recommendations

---

### 2.1 Safety instructions

---



#### DANGER

If you smell gas:

1. Do not use a naked flame, do not smoke, do not operate electrical contacts or switches ( doorbell, light, motor, lift, etc..).
2. Isolate the gas supply.
3. Open the windows.
4. Trace possible leaks and seal them immediately.
5. If the gas leak is before the gas meter, contact the gas supplier.



#### DANGER

If you smell flue gases:

1. Switch the appliance off.
2. Open the windows.
3. Trace possible leaks and seal them immediately.

### 2.2 Recommendations

---



#### WARNING

- ▶ Installation and maintenance of the boiler must be carried out by a qualified professional in compliance with prevailing local and national regulations.
- ▶ When working on the boiler, always disconnect the boiler from the mains and close the main gas inlet valve.
- ▶ After maintenance or repair work, check all installations to ensure that there are no leaks.



#### CAUTION

The boiler must be installed in a frost-free environment.



Keep this document close to the place where the boiler is installed.

#### Casing components

Only remove the casing for maintenance and repair operations. Put the casing back in place after maintenance and repair operations.

**Instructions stickers**

The instructions and warnings affixed to the appliance must never be removed or covered and must remain legible during the entire lifespan of the boiler. Immediately replace damaged or illegible instructions and warning stickers.

**Modifications**

Modifications may only be made to the boiler after the written permission of **De Dietrich Thermique** to do so.


## 3 Technical description

### 3.1 General description

#### Wall-hung gas condensing boilers

- ▶ High efficiency heating.
- ▶ Low pollutant emissions.
- ▶ Top of the range electronic **DIEMATIC iSystem** control panel
- ▶ Installation and connection facilitated by the mounting frame delivered with the appliance.
- ▶ Flue gas discharge via a forced flue, chimney, bi-flow or 3CE type connection.
- ▶ **MCA 15 - MCA 25**: Heating only (Possibility of producing domestic hot water via an independent tank which has been installed separately).
- ▶ **MCA 25/28 MI**: Heating and micro-storage domestic hot water production.

### 3.2 Main parts




T001867-C

- |    |  |
|----|--|
| 1  | Flue gas discharge pipe  |
| 2  | Casing/air box   |
| 3  | Outlet for measuring combustion gases  |
| 4  | Mixer pipe   |
| 5  | Heating flow hose  |
| 6  | Áir intake silencer  |
| 7  | Box for the control PCBs   |
| 8  | Combined venturi and gas valve unit  |
| 9  | Flow end hydrobloc   |
| 10 | Safety valve outlet pipe   |
| 11 | Siphon   |
| 12 | Control panel  |
| 13 | Shunt pump   |
| 14 | Return end hydrobloc   |
| 15 | Plate heat exchanger (DHW circuit) (Only on models with domestic hot water production) |
| 16 | Inverter valve   |
| 17 | Condensate receiver tank   |
| 18 | Fan  |
| 19 | Heat exchanger (Heating circuit)   |

- 20 Expansion vessel
- 21 Ignition/ionization electrode
- 22 Air intake

### 3.3 Operating principle


#### 3.3.1. Skeleton Diagrams



- 1 Heat exchanger (Heating circuit)
- 2 Hydrobloc
- 3 Plate heat exchanger (DHW circuit) (Only on models with domestic hot water production)
- 4 Heating flow
- 5 Domestic hot water outlet
- 6 Domestic cold water inlet
- 7 Heating return
- 8 Inverter valve
- 9 Shunt pump (Heating circuit)
- 10 Expansion vessel

T001868-B

#### 3.3.2. Shunt pump



T002537-B

- H Manometric height central heating circuit
- Q Water flow


The boiler is fitted with a modulating pump which is regulated by the control panel as a function of  $\Delta T$ .

The graph shows the manometric height at various outputs. The parameters **MIN.PUMP SPEED** and **MAX.PUMP SPEED** are used to modify the pump settings. If flow noise can be heard in the system, it is possible to reduce the maximum pump speed with the parameter **MAX.PUMP SPEED** (First of all, vent the heating system). If circulation in the radiators is too low or the radiators do not fully heat up, increase the minimum pump speed with the parameter **MIN.PUMP SPEED**.

See chapter: ""Professional" settings", page 82.

### 3.3.3. Water flow rate

The boiler's modulating control system limits the maximum difference in temperature between the heating flow and return and the maximum speed at which the flow temperature increases. In this way, the boiler does not require a minimum water flow rate.



- $\Delta p$  Pressure drop  
 $Q$  Water flow (max = 1680 l/h)

## 3.4 Technical characteristics

Boiler type			MCA 15	MCA 25	MCA 25/28 MI
<b>General</b>					
Flow rate setting	Adjustable		Modulating, Start/Stop, 0 - 10 V		
Nominal output (Pn) Heating System (80/60 °C)	minimum-maximum	kW	3,0 - 14,5	5,0 - 24,1	5,0 - 24,1
	Factory setting	kW	14,5	24,1	19,4
Nominal output (Pn) Heating System (50/30 °C)	minimum-maximum	kW	3,4 - 15,8	5,6 - 25,5	5,6 - 25,5
	Factory setting	kW	15,8	25,5	20,5
Nominal output (Pn) DHW System	minimum-maximum	kW	-	-	5,0 - 28,6
	Factory setting	kW	-	-	28,6
Nominal input (Qn) Heating System (Hi)	minimum-maximum	kW	3,1 - 15,0	5,2 - 25,0	5,2 - 25,0
	Factory setting	kW	15,0	25,0	20,1
Nominal input(Qn) Heating System (Hs)	minimum-maximum	kW	3,4 - 16,7	5,8 - 27,8	5,8 - 27,8
	Factory setting	kW	16,7	27,8	22,3
Nominal input (Qnw) DHW System (Hi)	minimum-maximum	kW	-	-	5,2 - 28,0
	Factory setting	kW	-	-	28,0
Nominal input (Qnw) DHW System (Hs)	minimum-maximum	kW	-	-	5,8 - 31,1
	Factory setting	kW	-	-	31,1
Heating efficiency under full load (Hi) (80/60 °C)	-	%	96,5	96,3	96,3
Heating efficiency under full load (Hi) (50/30 °C)	-	%	105,3	102,0	102,0
Heating efficiency under partial load (Hi) (Return temperature 60°C)	-	%	94,9	96,1	96,1
Heating efficiency under partial load (EN 92/42) (Return temperature 30°C)	-	%	108,5	108,0	108,0
<b>Data on the gases and combustion gases</b>					
Gas consumption - Natural gas H (G20)	minimum-maximum	m <sup>3</sup> /h	0,33 - 1,59	0,55 - 2,65	0,55 - 2,96
Gas consumption - Natural gas L (G25)	minimum-maximum	m <sup>3</sup> /h	0,38 - 1,85	0,64 - 3,08	0,64 - 3,45
Gas consumption - Propane G31	minimum-maximum	m <sup>3</sup> /h	0,13 - 0,61	0,21 - 1,02	0,21 - 1,15
NOx-Emission per year or (n =1)		mg/kWh	33	38	38
Mass flue gas flow rate	minimum-maximum	kg/h	5,3 - 25,2	8,9 - 42,1	8,9 - 47,1
Flue gas temperature	minimum-maximum	°C	30 - 65	30 - 80	30 - 85
(1) Front panel removed					

Boiler type			MCA 15	MCA 25	MCA 25/28 MI
Maximum counter pressure		Pa	80	120	130
<b>Characteristics of the heating circuit</b>					
Water content		l	1,7	1,7	1,7
Water operating pressure	minimum	kPa (bar)	80 (0,8)	80 (0,8)	80 (0,8)
Water operating pressure (PMS)	maximum	kPa (bar)	300 (3,0)	300 (3,0)	300 (3,0)
Water temperature	maximum	°C	110	110	110
Operating temperature	maximum	°C	90	90	90
Manometric height central heating circuit ( $\Delta T = 20K$ )		mbar	545	295	295
<b>Characteristics of the domestic hot water circuit</b>					
Specific hot water flow D (60 °C)		l/min	-	-	8,2
Specific hot water flow D (40 °C)		l/min	-	-	13,7
Domestic water resistance		mbar	-	-	490
Flow rate threshold	minimum	l/min	-	-	1,2
Water content		l	-	-	0,33
Operating pressure (Pmw)	maximum	kPa (bar)	-	-	800 (8,0)
<b>Electrical characteristics</b>					
Power supply voltage		VAC	230	230	230
Power consumption - Full load	maximum	W	101	116	124
	Factory setting	W	63	76	76
Power consumption - Part load	maximum	W	25	25	25
Power consumption - Standby	maximum	W	4	4	4
Electrical protection index			IPX4D	IPX4D	IPX4D
<b>Other characteristics</b>					
Weight (empty)	Total	kg	43	43	44
	Mounting <sup>(1)</sup>	kg	36	36	37
Acoustic level at 1 meter at high speed		dBA	35	42	44

(1) Front panel removed

### 3.4.1. Sensor characteristics

Outside sensor		Outlet sensor circuit B+C Domestic hot water sensor		Boiler sensor Return sensor	
-20 °C	2392 Ω	0 °C	32014 Ω	-20 °C	98932 Ω
-16 °C	2088 Ω	10 °C	19691 Ω	-10 °C	58879 Ω
-12 °C	1811 Ω	20 °C	12474 Ω	0 °C	36129 Ω
-8 °C	1562 Ω	25 °C	10000 Ω	10 °C	22804 Ω
-4 °C	1342 Ω	30 °C	8080 Ω	20 °C	14773 Ω
0 °C	1149 Ω	40 °C	5372 Ω	25 °C	12000 Ω
4 °C	984 Ω	50 °C	3661 Ω	30 °C	9804 Ω
8 °C	842 Ω	60 °C	2535 Ω	40 °C	6652 Ω
12 °C	720 Ω	70 °C	1794 Ω	50 °C	4607 Ω
16 °C	616 Ω	80 °C	1290 Ω	60 °C	3252 Ω
20 °C	528 Ω	90 °C	941 Ω	70 °C	2337 Ω
24 °C	454 Ω			80 °C	1707 Ω



Outside sensor		Outlet sensor circuit B+C Domestic hot water sensor		Boiler sensor Return sensor	
				90 °C	1266 Ω
				100 °C	952 Ω
				110 °C	726 Ω

# 4 Installation

## 4.1 Regulations governing installation



### WARNING

Installation of the appliance must be done by a qualified engineer in accordance with prevailing local and national regulations.

## 4.2 Package list

### 4.2.1. Standard delivery

The delivery includes:

- ▶ The boiler, fitted with a connection cable
- ▶ Mounting frame
- ▶ Mounting template
- ▶ Connection kit
- ▶ Run-off collector for siphon and safety valve
- ▶ Outside sensor
- ▶ Installation and Service Manual
- ▶ User Guide

### 4.2.2. Accessories

Various options are available depending on the configuration of the installation:


Boiler options		Control system options	
Description	package	Description	package
Stand-off frame	HR39	RX12 cable	AD134
Pipework kit for stand-off frame	HR40	TELCOM 2 voice remote monitoring module	AD152
Pipe cover	HR42	Flow sensor	AD199
Flue gas thermostat	HR43	DHW sensor	AD212
adapter 80/125	HR38	Optional PCB for 3-way valve	AD249
adapter 80-80	HR46	Hot water storage tank sensor	AD250
Exchanger cleaning kit	HR44	Outside radio-controlled temperature sensor	AD251
Boiler body cleaning kit	HR45	Boiler radio module	AD252
DHW tank BS60	EE54	Radio remote control	AD253
Kit for connection between MCA and BS60	EA138	Interactive remote control	AD254

Boiler options		Control system options	
Description	package	Description	package
DHW tank SR130	EE22	Room sensor	FM52
Kit for connection between MCA and SR130	EA137		

## 4.3 Choice of the location


### 4.3.1. Data plate

The data plate located on top of the boiler provides important information on the appliance: serial number, model, gas category, etc.



T001539-B

### 4.3.2. Location of the appliance



T001583-A

- ▶ Before mounting the boiler, decide on the ideal position for mounting, bearing the Directives and the dimensions of the appliance in mind.
- ▶ When choosing the position for mounting the boiler, bear in mind the authorised position of the combustion gas discharge outlets and the air intake opening.
- ▶ To ensure adequate accessibility to the appliance and facilitate maintenance, leave enough space around the boiler.



#### WARNING


- ▶ Fix the appliance to a solid wall capable of bearing the weight of the appliance when full of water and fully equipped.
- ▶ It is forbidden to store inflammable products and materials in the boiler room or close to the boiler, even temporarily.



#### CAUTION

- ▶ The boiler must be installed in a frost-free environment.
- ▶ A connection to the mains drainage system for the discharge of condensate must be available close to the boiler.

### 4.3.3. Ventilation



T001584-A


- (1) Distance between the front of the appliance and the internal wall of the cupboard.
- (2) Distance to allow on either side of the appliance.

If the boiler is installed in a closed box, respect the minimum dimensions given in the diagram opposite. Also allow openings to obviate the following hazards:










- ▶ Accumulation of gas
- ▶ Heating of the box

Minimum cross section of the openings:  $S1 + S2 = 150 \text{ cm}^2$


### 4.3.4. Main dimensions



T001116-B

-  Connection of the combustion gas exhaust pipe Ø 60 mm
-  Connection of the air intake pipe Ø 100 mm
-  Safety valve outlet pipe Ø 25 mm
-  Condensates discharge Ø 25 mm
-  Heating circuit return G<sup>3</sup>/<sub>4</sub>"
-  Domestic cold water inlet G<sup>1</sup>/<sub>2</sub>"
- Gas / Gaz**  Gas connection G<sup>1</sup>/<sub>2</sub>"
-  Domestic hot water outlet G<sup>1</sup>/<sub>2</sub>"
-  Heating circuit flow G<sup>3</sup>/<sub>4</sub>"

## 4.4 Installing the mounting frame



T001869-A

The boiler is delivered with a mounting template.

1. Position the mounting template to the wall with adhesive tape.



### CAUTION

Using a spirit level, check that the mounting axis is perfectly horizontal.


2. Drill 3 holes with a  $\varnothing$  of 10 mm.



Additional holes are provided in case one or other of the standard locating holes prevents the correct location of the plugs.


3. Put the plugs in place.
4. Secure the mounting frame to the wall using the 3 hexagonal headed screws provided for this purpose.

## 4.5 Positioning the boiler




1. Remove the protective caps from all of the hydraulic inlets and outlets on the boiler.

T001870-A



2. Fit a fibre gasket to each joint on the valve plate.

T001627-A



3. Position the boiler above the plumbing fixtures plate and locate it against the mounting frame. Gently lower the boiler.
4. Tighten the valve nuts on the boiler.

T001872-A

## 4.6 Hydraulic connections

### 4.6.1. Flushing the system

Installation must be carried out in accordance with the prevailing regulations, the codes of practice and the recommendations in these instructions.

#### ■ Installing the boiler in new installations (installations less than 6 months old)


- ▶ Clean the installation with a universal cleaner to eliminate debris from the appliance (copper, flaxen thread, flux).
- ▶ Thoroughly flush the installation until the water runs clear and shows no impurities.

#### ■ Installing the boiler in existing installations

- ▶ Remove sludge from the installation.
- ▶ Flush the installation.
- ▶ Clean the installation with a universal cleaner to eliminate debris from the appliance (copper, flaxen thread, flux).
- ▶ Thoroughly flush the installation until the water runs clear and shows no impurities.

### 4.6.2. Connection of the heating circuit

1. Connect the heating water outlet pipe to the heating flow connection.
2. Connect the heating water inlet pipe to the heating return connection.



T001625-A




Connection by internal brazing  $\varnothing$  22 mm



Connection by internal brazing  $\varnothing$  22 mm





T001633-B



- ▶ The boiler is factory fitted with a safety valve mounted on the left hydrobloc.




**CAUTION**

- ▶ The heating pipe must be mounted in accordance with prevailing provisions.

**4.6.3. Hydraulic connection of the water circuit for domestic use**

1. Connect the cold water inlet pipe to the domestic cold water connection.
2. Connect the domestic hot water outlet pipe to the domestic hot water connection.



T001626-A



Connection by internal brazing  $\varnothing$  16 mm



Connection by internal brazing  $\varnothing$  16 mm



**CAUTION**

- ▶ The domestic water pipes must be connected in accordance with prevailing provisions.
- ▶ If using synthetic pipes, follow the manufacturer's (connection) instructions.

**4.6.4. Connecting the expansion vessel**

The boiler is fitted as standard with an 12-litre expansion vessel.

If the water volume is greater than 150 litres or the static height of the system exceeds 5 metres, an additional expansion vessel must be fitted. Refer to the table below to determine the opened expansion vessel required for the installation.


**Conditions of validity of the table:**

- ▶ 3-bar safety valve
- ▶ Average water temperature: 70 °C  
Flow temperature: 80 °C  
Return temperature: 60 °C
- ▶ The filling pressure in the system is lower than or equal to the initial pressure in the opened expansion vessel

Initial pressure of the expansion vessel	Volume of the opened expansion vessel depending on the volume of the installation (in litres)							
	100	125	150	175	200	250	300	> 300
0.5 bar	4,8	6,0	7,2	8,4	9,6	12,0	14,4	Volume of the installation x 0,048
1 bar	8,0	10,0	12,0 <sup>(1)</sup>	14,0	16,0	20,0	24,0	Volume of the installation x 0,080
1.5 bar	13,3	16,6	20,0	23,3	26,6	33,3	39,9	Volume of the installation x 0,133

(1) Factory configuration

#### 4.6.5. Connecting the condensate discharge pipe



1. Mount a standard drainage pipe, Ø 32 mm or more, leading to the mains drainage system.
2. Mount the flow collector.
3. Into this, insert the condensate collector hose coming from the siphon (U) and the safety valve (S).
4. Into this, insert the discharge hose from the disconnector.
5. Mount a trap or a siphon in the discharge pipe.



#### CAUTION

Do not make a fixed connection owing to maintenance work on the siphon.



- ▶ Do not plug the condensate discharge pipe.
- ▶ Set the discharge pipe at a gradient of at least 30 mm per metre, maximum horizontal length 5 metres.
- ▶ Do not drain condensation water into a roof gutter at any time.
- ▶ Connect the condensate discharge pipe in accordance with prevailing standards.

#### 4.6.6. Filling the siphon




1. Remove the siphon.
2. Fill the siphon with water. This must be filled up to the level markers.
3. Re-assemble the siphon.



#### CAUTION

- ▶ Fill the water siphon before starting the boiler to avoid combustion products escaping from the boiler.
- ▶ Mount the vent hose above the siphon.

## 4.7 Gas connection



The diameters of the pipes must be defined in accordance with the standards in force in your country.



Connection by internal brazing  $\varnothing$  18 mm

1. Connect the gas inlet pipe.



### WARNING

- ▶ Close the main gas valve before starting work on the gas pipes.
- ▶ Before mounting, check that the gas meter has sufficient capacity. To do this, you should bear in mind the consumption of all domestic appliances.
- ▶ If the gas meter has too low a capacity, inform the energy supply company.




### CAUTION

- ▶ Ensure that there is no dust in the gas pipe. Blow into the pipe or shake it before mounting.
- ▶ We recommend installing a gas filter on the gas pipe to prevent clogging of the gas valve unit.
- ▶ Connect the gas pipe in accordance with prevailing standards and regulations.

## 4.8 Flue gas system connections

### 4.8.1. Classification



- 1 **Configuration C<sub>13</sub>**  
Air/flue gas connection by means of concentric pipes to a horizontal terminal (so-called forced flue)
- 2 **Configuration C<sub>33</sub>**  
Air/flue gas connection by means of concentric pipes to a vertical terminal (roof outlet)
- 3 **Configuration C<sub>93</sub>**  
Air/flue gas connection by concentric pipes in the boiler room and single pipes in the chimney (combustive air in counter current in the chimney)

- 4 Configuration C<sub>93</sub>**  
Air/flue gas connection by concentric pipes in the boiler room and single "flex" in the chimney (combustive air in counter current in the chimney)

**WARNING**

- ▶ Only factory components are authorised for connecting the boiler and the terminal.
- ▶ The clear section must comply with the standard.
- ▶ The chimney must be swept before the installation of the evacuation conduit.

- 5 Configuration C<sub>53</sub>**  
Air and flue gas connection separated by means of a bi-flow adapter and single pipes (combustive air taken from outside)
- 6 Configuration B<sub>23</sub>**  
Connection to a chimney using a connection kit (combustive air taken from the boiler room)
- 12 Configuration C<sub>43</sub>**  
Air/flue gas connection to a collective conduit for watertight boilers (3CE system)

#### 4.8.2. Lengths of the air/flue gas pipes

Type of air/flue gas connection			Diameter	Maximum length in metres		
				MCA 15	MCA 25	MCA 25/28 MI
C <sub>13</sub>	Concentric pipes connected to a horizontal terminal	Alu or PPS	60/100 mm	12.0	3.5	4.2
			80/125 mm	12.3	23.0	25.7
C <sub>33</sub>	Concentric pipes connected to a vertical terminal	Alu or PPS	60/100 mm	13.0	4.9	5.5
			80/125 mm	10.7	21.0	23.6
C <sub>93</sub>	Concentric pipes in the boiler room Single conduits in the chimney (combustive air in counter-current)	Alu or PPS	60/100 mm 60 mm (Rigid duct)	15.0	8.1	9.1
	Concentric pipes in the boiler room Flexible single conduit in the chimney	PPS	60/100 mm 80 mm (Flexible duct)	9.9	20.0	22.7
C <sub>53</sub>	Bi-flow adapter and separate single air/flue gas ducts (combustive air taken from outside)	Alu	60/100 mm 2 x 80 mm	50.0	50.0	50.0
B <sub>23</sub>	Chimney (rigid or flexible duct in furnace flue, combustive air taken from the premises)	PPS	80 mm (Rigid duct)	50.0	50.0	50.0
			80 mm (Flexible duct)	45.0	45.0	45.0

**WARNING**

Maximum length = lengths of the straight air/flue gas ducts + equivalent lengths of other components

For the list of flue gas system accessories and the equivalent lengths, refer to the current price list.

## 4.9 Installing the outside sensor


### 4.9.1. Choice of the location

It is important to select a place that allows the sensor to measure the outside conditions correctly and effectively.

#### Advised positions:


- ▶ on one face of the area to be heated, on the north if possible
- ▶ half way up the wall in the room to be heated
- ▶ under the influence of meteorological variations
- ▶ protected from direct sunlight
- ▶ easy to access

- A** Recommended position  
**B** Possible position  
**H** Inhabited height controlled by the sensor  
**Z** Inhabited area controlled by the sensor




#### Positions to be avoided:

- ▶ masked by a building element (balcony, roof, etc.)
- ▶ close to a disruptive heat source (sun, chimney, ventilation grid, etc.)



### 4.9.2. Installing the outside sensor

Mount the sensor using the screws and dowels provided.



- ① CB wood screws diameter 4 + dowels

## 4.10 Electrical connections

### 4.10.1. Control unit


The boiler is fully pre-wired. The mains supply is made via the cable **C** connected to the mains. All other external connections can be made to the connection connectors (low voltage). The main characteristics of the control unit are described in the table below.

Power supply voltage	230 VAC/50Hz
Rating of the main fuse F1 (230 VAC)	6.3 AT
Fuse rating F2 (230 VAC)	2 AT
Fan-DC	27 VDC



#### CAUTION

Keep to the polarity shown on the terminals: phase (L), neutral (N) and earth  $\frac{1}{\text{E}}$ .



- A** Routing of the 230 V cables
- B** Routing of the sensor cables
- C** Power supply cable
- D** 6,3 AT fuse
- E** 2 AT fuse



#### CAUTION

The following components of the appliance are at a voltage of 230 V:

- ▶ Boiler pump.
- ▶ Combined venturi and gas valve unit.
- ▶ Inverter valve.
- ▶ The majority of components in the control panel and the terminal box.
- ▶ Power supply cable.

C002336-E

## 4.10.2. Recommendations

---



### WARNING

- ▶ Only qualified professionals may carry out electrical connections, always with the power off.
- ▶ The boiler is entirely pre-wired. Do not modify the connections inside the control panel.
- ▶ Earth the appliance before making any electrical connections.

Make the electrical connections of the appliance according to:

- ▶ the instructions of the prevailing standards.
- ▶ the instructions on the circuit diagrams provided with the appliance.
- ▶ the recommendations in the instructions.




### CAUTION

- ▶ Separate the sensor cables from the 230 V cables.
- ▶ Outside the boiler: Use 2 pipes or cable guides at least 10 cm apart.



### 4.10.3. Position of the PCBs




- ① Do not connect anything to the terminal block.
- ② Optional PCB (Package AD249)
- ③ Do not connect anything to the terminal block.


#### 4.10.4. Accessing the connection terminal blocks


To access the connection terminal blocks, proceed as follows:

1. Unscrew the 2 screws under the front panel by a quarter turn.
2. Remove the front panel.




3. Open the holding clips located on the sides.
4. Tilt the control panel forward.






5. Lift the clip located in front of the control panel.
6. Lift the control panel cover.



7. Unclip the PCB cover.


### 4.10.5. Connecting a direct heating circuit



- ① Do not connect anything to the terminal block.
- ② Connect the outside temperature sensor.
- ③ Connect a safety thermostat if the heating circuit is for underfloor heating.
  - ▶ Remove the bridge.
  - ▶ Connect the wires from the safety thermostat to the connector.
- ④ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level #SYSTEM menu	<b>EXTENDED</b>	"Displaying the parameters in extended mode", page 71
If safety thermostat is connected to <b>BL</b> on the connection terminal block: <b>IN.BL</b>	"Installer" level #PRIMARY INSTAL.P menu	<b>STOP HEAT</b>	""Professional" settings", page 82

### 4.10.6. Connecting a direct heating circuit and a domestic hot water tank




① Do not connect anything to the terminal block.

②



**CAUTION**

Do not connect anything to the  outlet on the terminal block. The reversal valve is connected to the PCU PCB in the boiler.

③

Connect the outside temperature sensor.

④

Connect a safety thermostat if the heating circuit is for underfloor heating.




- ▶ Remove the bridge.
- ▶ Connect the wires from the safety thermostat to the connector.

- ⑤ Connect the DHW tank anode.


**CAUTION**

- ▶ If the tank is fitted with a Titan Active System® impressed current anode, connect the anode to the inlet (+ on the anode, - on the tank).
- ▶ If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).

- ⑥ Connect the DHW sensor (Package AD212).
- ⑦ Connect the domestic hot water looping pump (Optional).
- ⑧ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
If a domestic hot water looping pump is connected to <b>DA</b> on the terminal block: <b>O.PUMP A</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>DHW LOOP</b>	 "Setting the parameters specific to the installation", page 72
If safety thermostat is connected to <b>BL</b> on the connection terminal block: <b>IN.BL</b>	"Installer" level <b>#PRIMARY INSTAL.P</b> menu	<b>TOTAL STOP</b>	 ""Professional" settings", page 82
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b>			

### 4.10.7. Connecting two circuits and a domestic hot water tank before the mixing tank




① Do not connect anything to the terminal block.

②



#### CAUTION

Do not connect anything to the  outlet on the terminal block. The reversing valve is connected to the PCU PCB in the boiler.

③ Connect the outside temperature sensor.

④ Connect a safety thermostat if the heating circuit is for underfloor heating.

- ▶ Remove the bridge.
- ▶ Connect the wires from the safety thermostat to the connector.

⑤ Connecting an additional circuit to the AD249 option.

⑥ Connect the heating pump (circuit **A**).



If underfloor heating is being used, put a safety thermostat in place after the heating pump. The safety thermostat will shut down the heating pump in the event of overheating.

⑦ Low loss header.

⑧ Connect the DHW tank anode.



#### CAUTION

- ▶ If the tank is fitted with a Titan Active System® impressed current anode, connect the anode to the inlet (+ on the anode, - on the tank).
- ▶ If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).

⑨ Connect the heating pump (circuit **B**).

⑩ Connect the 3-way valve (circuit **B**).


⑪ Connect the DHW sensor (Package AD212).

⑫ Connect the domestic hot water looping pump to the **AUX** outlet on the AD249 option

⑬ Do not connect anything to the terminal block.



### 4.10.8. Connecting two circuits and a domestic hot water tank after the mixing tank



- ① Do not connect anything to the terminal block.
- ② Connect the outside temperature sensor.
- ③ Connect a safety thermostat if the heating circuit is for underfloor heating.
  - ▶ Remove the bridge.
  - ▶ Connect the wires from the safety thermostat to the connector.
- ④ Low loss header
- ⑤ Connecting an additional circuit to the AD249 option.

⑥ Connect the heating pump (circuit **A**).



If underfloor heating is being used, put a safety thermostat in place after the heating pump. The safety thermostat will shut down the heating pump in the event of overheating.

⑦ Connect the DHW tank anode.



#### CAUTION

- ▶ If the tank is fitted with a Titan Active System® impressed current anode, connect the anode to the inlet (+ on the anode, - on the tank).
- ▶ If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).



⑧ Connect the heating pump (circuit **B**).

⑨ Connect the 3-way valve (circuit **B**).

⑩ Connect the DHW sensor (Package AD212).

⑪ Connect the domestic hot water looping pump to the **AUX** outlet on the AD249 option.

⑫ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level #SYSTEM menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>O.DHW:</b> <sup>(1)</sup>	"Installer" level #SYSTEM menu	<b>PUMP</b>	 "Setting the parameters specific to the installation", page 72


(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

### 4.10.9. Hot water storage tank connection

#### ■ QUADRO DU 750 storage tank

In this installation example, the storage tank (type QUADRO DU 750) incorporates a domestic hot water zone. The boiler starts up systematically to maintain the domestic hot water zone in the storage tank or to maintain the independent tank at temperature.

**i** If the storage tank does not have a DHW zone, use an independent domestic hot water tank.





- ① Do not connect anything to the terminal block.
- ② Connect the heating pump (Circuit A).
- ③ Connect the DHW tank anode.

**i** If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).

- ④ Connect the DHW sensor (Package AD212).
- ⑤ Connect the sensor from the storage tank (Package AD250).

- ⑥ Buffer tank.
- ⑦ Solar sensor probe.
- ⑧ Connect the solar station to the solar collectors.
- ⑨ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>I.SYST</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>STORAGE TANK</b>	 "Setting the parameters specific to the installation", page 72

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**




The DHW part is maintained at the DHW set point by the boiler.

The heating zone is maintained at the set temperature calculated according to the outside temperature. The zone is reheated when the heating buffer temperature sensor ⑤ falls -6°C below the calculated set temperature. Reheating in the heating zone stops when the heating buffer temperature rises above the calculated set temperature.



■ PS storage tank and DHW tank connected to the boiler

The boiler only starts up if the storage tank is not hot enough to guarantee loading of the DHW tank.



- ① Connect a domestic hot water tank if the storage tank ④ is only used for heating
- ② Connect the DHW sensor (Package AD212).
- ③ Connect the heating pump (Circuit A).
- ④ Buffer tank.
- ⑤ Connect the sensor from the storage tank.
- ⑥ Solar sensor probe.
- ⑦ Connect the solar station to the solar collectors.

- ⑧ Connect the DHW tank anode.
- i** If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).
- ⑨ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>I.SYST</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>STORAGE TANK</b>	 "Setting the parameters specific to the installation", page 72
<b>O.DHW</b> : <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>PUMP</b>	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**




The DHW part is maintained at the DHW set point by the boiler.

The heating zone is maintained at the set temperature calculated according to the outside temperature. The zone is reheated when the heating buffer temperature sensor falls -6°C below the calculated set temperature. Reheating in the heating zone stops when the heating buffer temperature rises above the calculated set temperature.

#### ■ PS storage tank and DHW tank connected to the storage tank

The boiler only starts up production of domestic hot water if the storage tank is not hot enough to guarantee tank loading.



① Do not connect anything to the terminal block.

② Connect the heating pump (Circuit A).

③ Connect the DHW tank anode.

**i** If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).

④ Buffer tank.

⑤ Solar sensor probe.

⑥ Connect the solar station to the solar collectors.

⑦ Domestic hot water boiler.  
Connect the DHW sensor.

⑧ Do not connect anything to the terminal block.


Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
INSTALLATION	"Installer" level #SYSTEM menu	EXTENDED	"Displaying the parameters in extended mode", page 71
I.SYST <sup>(1)</sup>	"Installer" level #SYSTEM menu	ST.TANK+DHW	"Setting the parameters specific to the installation", page 72
O.DHW: <sup>(1)</sup>	"Installer" level #SYSTEM menu	PUMP	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**



The DHW tank is loaded from the storage tank. If, during DHW loading, the temperature of the storage tank falls below the primary DHW set point (parameter PRIM.TEMP.DHW), the boiler maintains the latter at temperature to guarantee the loading of the DHW tank. The heating zone is maintained at the set temperature calculated according to the outside temperature. The zone is reheated when the heating buffer temperature sensor falls -6°C below the calculated set temperature. Reheating in the heating zone stops when the heating buffer temperature rises above the calculated set temperature.




#### 4.10.10. Pool connection



- ① Connect the secondary swimming pool pump.
- ② Connect the swimming pool sensor.
- ③ Plate heat exchanger.



- ④ Pool heating cut-off control
- i** When the parameter **I.TEL:** is on **0/1 B**, the swimming pool is no longer heated when the contact is open (factory setting), only the antifreeze continues to be active. The contact direction can still be adjusted by the parameter **CT.TEL**.
- ⑤ Connect the primary swimming pool pump.
- ⑥ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>CIRC. B:</b>	"Installer" level <b>#SYSTEM</b> menu	<b>SWIM.P.</b>	 "Setting the parameters specific to the installation", page 72
If <b>I.TEL:</b> is used	"Installer" level <b>#SYSTEM</b> menu	<b>0/1 B</b>	
<b>MAX. CIRC. B</b>	"Installer" level <b>#SECONDARY LIMITS</b> menu	Set the value of <b>MAX.CIRC.B</b> to the temperature corresponding to the needs of the exchanger	 ""Professional" settings", page 82

## ■ Controlling the pool circuit

The control system can be used to manage a swimming pool circuit in both cases:

### Case 1: The control system regulates the primary circuit (boiler/exchanger) and the secondary circuit (exchanger/pool).

- ▶ Connect the primary circuit pump (boiler/exchanger) to the **◀B** outlet on the connection terminal block. The temperature **MAX.CIRC.B** is then guaranteed during comfort periods on programme **B** in summer and winter alike.
- ▶ Connect the swimming pool sensor (package AD212) to the **S DEP B** inlet on the connection terminal block.
- ▶ Set the set point of the pool sensor using key **↓** in the range 5 - 39°C.

### Case 2: The pool has already a regulation system that is to be kept. The control system only regulates the primary circuit (boiler/exchanger).

- ▶ Connect the primary circuit pump (boiler/exchanger) to the **◀B** outlet on the connection terminal block. The temperature **MAX.CIRC.B** is then guaranteed during comfort periods on programme **B** in summer and winter alike.

**i** The swimming pool can also be connected to circuit **C** by adding the AD249 option:

- ▶ Make the connection to the terminal blocks marked **C**.
- ▶ Set the parameters for circuit **C**.


### Hourly programming of the secondary circuit pump

The secondary pump operates during programme **B** comfort periods in summer and winter alike.

### Stopping

To prepare your pool for winter, consult your pool specialist.

#### 4.10.11. Connecting a mixed tank



- ① Do not connect anything to the terminal block.
- ② Option of connecting the electric tank (with AD249 option) or to ③
- ③ Outlet circuit **A** - Option of connecting the electric tank (or to ②)
- ④ Power control relay to the electrical resistor


- ⑤ Connect the DHW tank anode.
  - i** If the tank is not fitted with an impressed current anode, put the simulation connector in place (delivered with the DHW sensor - package AD212).
- ⑥ Connect the DHW sensor (Package AD212).
- ⑦ Connect the outside temperature sensor
- ⑧ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level #SYSTEM menu	<b>EXTENDED</b>	"Displaying the parameters in extended mode", page 71
If the electric tank is connected to <b>▶A:</b> <b>CIRC. A:</b> <sup>(1)</sup>	"Installer" level #SYSTEM menu	<b>DHW ELEC</b>	"Setting the parameters specific to the installation", page 72
If the electric tank is connected to <b>▶AUX:</b> <b>S.AUX:</b> <sup>(1)</sup>	"Installer" level #SYSTEM menu	<b>DHW ELEC</b>	



(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

### 4.10.12. Connecting the options

For example: TELCOM remote vocal monitoring module, remote controls for circuits **A** and **B**, second DHW tank




- ① Do not connect anything to the terminal block.
- ② Connect the load pump to the second tank.
- ③ Second domestic hot water tank
- ④ Connect the DHW sensor from the second tank.
- ⑤ Alarm indicator
- ⑥ Connect the TELCOM remote vocal monitoring module (depending on its availability in your country).
- ⑦ Connecting the BUS cascade, VM
- ⑧ Connect the remote control (Package AD254/FM52).
- ⑨ Do not connect anything to the terminal block.

Settings to be made for this type of installation			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level #SYSTEM menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>O.PUMP A<sup>(1)</sup></b>	"Installer" level #SYSTEM menu	<b>FAILURE</b>	 "Setting the parameters specific to the installation", page 72
If second tank connected: <b>S.AUX:<sup>(1)</sup></b>	"Installer" level #SYSTEM menu	<b>DHW</b>	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**




### 4.10.13. Connection in cascade

#### ■ DHW tank after the mixing tank





- ① Master boiler
- ② Secondary boiler

- ③ Secondary boiler
- ④ D.H.W. load pump
- ⑤ Connect the DHW sensor (Package AD212)
- ⑥ Cable **BUS**
- ⑦ Low loss header
- ⑧ Cascade outlet sensor  
Connect the sensor to the terminal block **S SYST** on the master boiler.


Settings to be made for this type of installation: Master boiler			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>O.DHW:</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>PUMP</b>	 "Setting the parameters specific to the installation", page 72
<b>CASCADE:</b> <sup>(1)</sup>	"Installer" level <b>#NETWORK</b> menu	<b>ON</b>	 "Configuring the network", page 88
<b>MASTER CONTROLLER</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>ON</b>	
<b>SYSTEM NETWORK</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>ADD SLAVE</b>	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

Settings to be made for this type of installation: Follower boilers			
Parameters	Access	Settings to be made	See chapter
<b>INSTALLATION</b>	"Installer" level <b>#SYSTEM</b> menu	<b>EXTENDED</b>	 "Displaying the parameters in extended mode", page 71
<b>CASCADE:</b> <sup>(1)</sup>	"Installer" level <b>#NETWORK</b> menu	<b>ON</b>	 "Configuring the network", page 88
<b>MASTER CONTROLLER</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	<b>OFF</b>	
<b>SLAVE NUMBER</b> <sup>(1)</sup>	"Installer" level <b>#SYSTEM</b> menu	2, 3, ...	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

■ DHW tank on master boiler



- ① Connect the DHW sensor (Package AD212)
- ② Master boiler
- ③ Secondary boiler
- ④ Secondary boiler
- ⑤ Low loss header
- ⑥ Cascade outlet sensor  
Connect the sensor to the terminal block **S SYST** on the master boiler.


Settings to be made for this type of installation: Master boiler			
Parameters	Access	Settings to be made	See chapter
INSTALLATION	"Installer" level #SYSTEM menu	EXTENDED	☞ "Displaying the parameters in extended mode", page 71
O.DHW: <sup>(1)</sup>	"Installer" level #SYSTEM menu	RV	☞ "Setting the parameters specific to the installation", page 72
CASCADE: <sup>(1)</sup>	"Installer" level #NETWORK menu	ON	☞ "Configuring the network", page 88
MASTER CONTROLLER <sup>(1)</sup>	"Installer" level #SYSTEM menu	ON	
SYSTEM NETWORK <sup>(1)</sup>	"Installer" level #SYSTEM menu	ADD SLAVE	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

Settings to be made for this type of installation: Follower boilers			
Parameters	Access	Settings to be made	See chapter
INSTALLATION	"Installer" level #SYSTEM menu	EXTENDED	☞ "Displaying the parameters in extended mode", page 71
CASCADE: <sup>(1)</sup>	"Installer" level #NETWORK menu	ON	☞ "Configuring the network", page 88
MASTER CONTROLLER <sup>(1)</sup>	"Installer" level #SYSTEM menu	OFF	
SLAVE NUMBER <sup>(1)</sup>	"Installer" level #SYSTEM menu	2, 3, ...	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**

### 4.11 Electrical diagram



T001871-H

<b>P</b>	Power supply	<b>DV</b>	Inverter valve	<b>FTS</b>	Flow sensor
<b>SCU-C</b>	control panel PCB	<b>PUMP A</b>	Modulating control on the boiler pump	<b>PS</b>	Pressure sensor
<b>S</b>	On/Off switch	<b>HLS</b>	Safety thermostat	<b>PSU</b>	Parameter storage for PCBs PCU and SU
<b>IT</b>	Ignition transformer	<b>FAN</b>	Fan	<b>PWM PUMP</b>	Modulation signal from the boiler pump
<b>E</b>	Ignition power relay	<b>FS</b>	Flowmeter	<b>DIS</b>	Display
<b>GB</b>	Combined venturi and gas valve unit	<b>RTS</b>	Return sensor		

## 4.12 Filling the system

### 4.12.1. Water treatment

Treat the water in the installation to limit corrosion, calcium and limescale deposits, sludge, microbiological contamination, etc..



#### CAUTION

An uncleaned installation or an installation using water of unsuitable quality may bring about the cancellation of the warranty.

For an optimum functioning of the boiler, the water of the installation must comply with following characteristics:

		Output (kW)			
		≤ 70	70 - 200	200 - 550	≥ 550
Degree of acidity (water non-treated)	pH	7 - 9	7 - 9	7 - 9	7 - 9
Degree of acidity (water treated)	pH	7 - 8.5	7 - 8.5	7 - 8.5	7 - 8.5
Conductivity at 25°C	μS/cm	≤ 800	≤ 800	≤ 800	≤ 800
Chlorides	mg/l	≤ 150	≤ 150	≤ 150	≤ 150
Other components	mg/l	< 1	< 1	< 1	< 1
Water hardness	°f	1 - 35	1 - 20	1 - 15	1 - 5
	°dH	0.5 - 20.0	0.5 - 11.2	0.5 - 8.4	0.5 - 2.8
	mmol/l	0.1 - 3.5	0.1 - 2.0	0.1 - 1.5	0.1 - 0.5

#### Recommendations:

- ▶ Reduce the quantity of oxygen in the heating circuit to the minimum.
- ▶ Limit the annual quantity of water added to the circuit to 5% of the total water volume in the installation.
- ▶ New installation
  - Completely clean the installation of all residues (plastic waste, installation parts, oils, etc.).
  - Use an inhibitor in combination with a softener.
- ▶ Existing installation
 

If the water quality in the installation is insufficient, several options are possible:

  - Install one or more filters.
  - Completely clean the installation to evacuate any impurities and deposits in the heating circuit. To do this, a considerable and controlled flow rate is required.
  - Clean the boiler (dirt, deposits, calcium, etc.).

De Dietrich Thermique recommends the following products:

Manufacturer	Product	Function
FernoX	Restorer	Universal cleaner for existing installations
	Protector	protective product
	Alphi 11	Antifreeze and inhibitor




Manufacturer	Product	Function
GE-Water / Betzdearborn	Sentinel X100	protective product
	Sentinel X200	Limescale remover
	Sentinel X300	protective product for new installations
	Sentinel X400	protective product for existing installations
	Sentinel X500	Antifreeze and inhibitor

Other manufacturers propose similar products.

**CAUTION**

- ▶ Check the compatibility of the product with the materials used in the installation.
- ▶ Respect the manufacturer's instructions (use, dose, etc.) to obviate any hazards (corporal, material, environmental).

### 4.12.2. Filling the system




T000181-B

**CAUTION**


Before filling, open the valves on every radiator in the installation.

1. Open the cold water inlet and heating outlet valves.




T001620-A

2. Open the disconnecter valves (During filling, air can escape from the system via the automatic air vent).



T001618-A

3. Close the disconnecter valves when the manometer indicates a pressure of 2 bar



T001619-A

4. Check the tightness of the water connections.




**Check  
Contrôler**

T001507-A

# 5 Start-up

## 5.1 Control panel


### 5.1.1. Description of the keys










- A** Temperature setting key (heating, DHW, swimming pool)
- B** Operating mode selection key
- C** DHW override key
- D** Key to access the parameters reserved for the installer
- E** Keys on which the function varies as and when selections are made
- F** Rotary setting button:
  - ▶ Turn the rotary button to scroll through the menus or modify a value
  - ▶ Press the rotary button to access the menu selected or confirm a value modification


## 5.1.2. Description of the display





### ■ Key functions




- ➔ Access to the various menus
-  Used to scroll through the menus
-  Used to scroll through the parameters
- ? The symbol is displayed when help is available
-  Used to display the curve of the parameter selected
- STD** Reset of all time programmes
-  Selection of comfort mode or selection of the days to be programmed
-  Selection of reduced mode or deselection of the days to be programmed
-  Back to the previous level
- ESC** Back to the previous level without saving the modifications made
-  Manual reset

### ■ Flame output level




-  C0002705-A The whole symbol flashes: The burner starts up but the flame is not yet present
-  C0002704-A Part of the symbol flashes: Output is increasing
-  C0002703-A Steady symbol: The required output has been reached
-  C0002702-A Part of the symbol flashes: Output is dropping

### ■ Operating modes



Summer mode: The heating is off. Domestic hot water continues to be produced



WINTER mode: Heating and domestic hot water working

#### AUTO

Operation in automatic mode according to the timer programme



Comfort mode: The symbol is displayed when a DAY override (comfort) is activated

- ▶ Flashing symbol: Temporary override
- ▶ Steady symbol: Permanent override



Reduced mode: The symbol is displayed when a NIGHT override (reduced) is activated

- ▶ Flashing symbol: Temporary override
- ▶ Steady symbol: Permanent override




Holiday mode: The symbol is displayed when a HOLIDAY override (antifreeze) is activated

- ▶ Flashing symbol: Holiday mode programmed
- ▶ Steady symbol: Holiday mode active



Manual mode

### ■ System pressure



#### bar

Pressure indicator: The symbol is displayed when a water pressure sensor is connected


- ▶ Flashing symbol: The quantity of water is insufficient
- ▶ Steady symbol: The quantity of water is sufficient



Water pressure level


- ▶ . : 0,9 to 1,1 bar
- ▶ . : 1,2 to 1,5 bar
- ▶ . : 1,6 to 1,9 bar
- ▶ . : 2,0 to 2,3 bar
- ▶ . : > 2,4 bar

■ Domestic Hot Water override



A bar is displayed when a DHW override is activated:

- ▶ Flashing bar: Temporary override
- ▶ Steady bar: Permanent override



■ Other information


- The symbol is displayed when domestic hot water production is running
- Valve indicator: The symbol is displayed when a 3-way valve is connected
  - ▶ : 3-way valve open
  - ▶ : 3-way valve closed
- The symbol is displayed when the pump is operating
- Name of the circuit for which the parameters are displayed

5.1.3. Access to the various browsing levels

■ "User" level


The information and settings in the "User" level can be accessed by everyone.

1. Press the → key.





### ■ "Installer" level

The information and settings in the "Installer" level can be accessed by experienced people.

1. Press key  for around 5 seconds.




Before the "Installer" level is displayed, the **EMISSION MEASUREMENTS** menu will be displayed. Hold down the  key until **#LANGUAGE** is displayed.




C002235-F-04


### ■ "After Sales" level

The information and settings in the "After Sales" level can be accessed by initiates.

1. Press key  for around 10 seconds.




Before the "After Sales" level is displayed, the "Installer" level will be displayed. Hold key  down until **#PARAMETERS** is displayed.




C002272-C-04

### 5.1.4. Browsing in the menus




C002220-A-04

1. To select the desired menu, turn the rotary button.
  2. To access the menu, press the rotary button.
- To go back to the previous display, press the key  $\leftarrow$ .



C002221-B-04

3. To select the desired parameter, turn the rotary button.
  4. To modify the parameter, press the rotary button.
- To go back to the previous display, press the key  $\leftarrow$ .




C002222-B-04

5. To modify the parameter, turn the rotary button.
6. To confirm, press the rotary button.



To cancel, press key  $\text{ESC}$ .



C002224-D-04

7. To go back to the main display, press key  $\leftarrow$  2 times.



It is possible to use the  $\leftarrow$  and  $\rightarrow$  keys instead of the rotary button.



## 5.2 Check points before commissioning

---

### 5.2.1. Preparing the boiler for commissioning

---

**WARNING**

Do not put the boiler into operation if the supplied gas is not in accordance with the approved gas types.

**Preparatory procedure for boiler commissioning:**

- ▶ Check that the gas type supplied matches the data shown on the boiler's data plate.
- ▶ Check the gas circuit.
- ▶ Check the hydraulic circuit.
- ▶ Check the water pressure in the heating system.
- ▶ Check the electrical connections to the thermostat and the other external controls.
- ▶ Check the other connections.
- ▶ Test the boiler at full load. Check the setting of the gas/air ratio and, if necessary, correct it.
- ▶ Test the boiler at part load. Check the setting of the gas/air ratio and, if necessary, correct it.
- ▶ Finalizing work.

### 5.2.2. Gas circuit




#### WARNING

Ensure that the boiler is switched off.


1. Open the main gas supply.
2. Unscrew the two screws located under the front panel by a quarter turn and remove the panel.
3. Tilt the control box forwards by opening the holding clips located at the sides.
4. Check the gas supply pressure at the measurement point **C** on the gas valve unit.



#### WARNING

 To ascertain the gas types permitted, see chapter: "Gas categories", page 8

5. Check the tightness of the gas connections made after the gas valve unit in the boiler.
6. Check the leak tightness of the gas inlet, including the gas valves. The test pressure must not exceed 60 mbar.
7. Purge the gas supply pipe within the boiler by unscrewing the measurement point on the gas block. Tighten the measurement point when the pipe has been sufficiently purged.
8. Check the tightness of the gas connections in the boiler.



T001518-B

### 5.2.3. Hydraulic circuit



- ▶ Check the condensate discharge siphon; it must be filled with clean water up to the mark.
- ▶ Check that there are no leaks on the hydraulic connections.

### 5.2.4. Electrical connections

- ▶ Check the electrical connections.

## 5.3 Putting the appliance into operation

1. Tilt the control box upwards again and fasten it using the clips located at the sides.
2. Open the main gas supply.
3. Open the gas valve on the boiler.
4. Turn on the boiler using the on/off switch.



5. The first time the boiler is powered up, the **#LANGUAGE** menu is displayed. Select the desired language by turning the rotary button.
6. To confirm, press the rotary button.

The boiler will begin an automatic venting-programme (which lasts approx. 3 minutes) and will do this every time the power supply is isolated.

### Error during the start-up procedure:

- ▶ No information is shown on the display:
  - Check the mains supply voltage
  - Check the fuses
  - Check the connection of the power cable to the connector X1 on the PCU PCB
- ▶ If there is a problem, the error is displayed on the screen.
  - ▶ See chapter: "Messages (Code type Bxx or Mxx)", page 112



If a DHW sensor is connected and the anti-legionella function is activated, the boiler starts to heat the water in the DHW tank as soon as the vent programme has been completed. The heating time depends on the size of the DHW installation.

## 5.4 Gas settings

---

### 5.4.1. Adapting to another gas type

---






#### WARNING

Only a qualified engineer may carry out the following operations.


The boiler is preset in the factory to operate on natural gas H (G20).

For operation on another group of gases, carry out the following operations:

- ▶ Set the air/gas ratio.
  -  "Setting the air/gas ratio (Full load)", page 67
  -  "Setting the air/gas ratio (Part load)", page 69
- ▶ Set the fan speed using the parameters **MIN. VENT.**, **MAX. VENT. BOIL**, **MAX. VENT. DHW** and **START SP.**:
  -  See chapter: ""Professional" settings", page 82

### 5.4.2. Setting the air/gas ratio (Full load)

1. Unscrew the plug of the flue gas measurement point.
2. Connect the flue gas analyser.




**WARNING**

Ensure that the opening around the sensor is completely sealed when taking measurements.


3. In the main display, press key . The menu **EMISSION MEASUREMENTS** is displayed on the screen.




If an automatic vent cycle is running, it is not possible to perform these operations.




4. Select the generator desired. The characteristics of the generator are displayed.



5. Turn the rotary button until **PMAX** is displayed. The full load is set.
6. Measure the percentage of O<sub>2</sub> or CO<sub>2</sub> in the flue gases (Front panel removed) .





T000932-A

7. If this rate does not match the required value, correct the gas/air ratio using the adjustment screw A on the gas valve unit.
8. Check the flame through the flame viewport.




The flame must not be detached.

O <sub>2</sub> /CO <sub>2</sub> control and setting values for gas H (G20) at full load				
Boiler type	Setting value		Checking value	
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)
MCA 15	5,2 ± 0,4	8,8 ± 0,2	5,2 ± 0,5	8,8 ± 0,3
MCA 25	5,2 ± 0,4	8,8 ± 0,2	5,2 ± 0,5	8,8 ± 0,3
MCA 25/28 MI	5,2 ± 0,4	8,8 ± 0,2	5,2 ± 0,5	8,8 ± 0,3

O <sub>2</sub> /CO <sub>2</sub> control and setting values for gas L (G25) at full load				
Boiler type	Setting value		Checking value	
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)
MCA 15	4,9 ± 0,4	8,8 ± 0,2	4,9 ± 0,5	8,8 ± 0,3
MCA 25	4,9 ± 0,4	8,8 ± 0,2	4,9 ± 0,5	8,8 ± 0,3
MCA 25/28 MI	4,9 ± 0,4	8,8 ± 0,2	4,9 ± 0,5	8,8 ± 0,3

O <sub>2</sub> /CO <sub>2</sub> control and setting values for propane (G31) at full load					Diameter allowed for the gas diaphragm (x.xx)
Boiler type	Setting value		Checking value		Fit the gas restrictor in the gas block Ø mm
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	
MCA 15	5,2 ± 0,3	10,3 ± 0,2	5,2 ± 0,5	10,3 ± 0,3	3,00
MCA 25	5,2 ± 0,3	10,3 ± 0,2	5,2 ± 0,5	10,3 ± 0,3	4,00
MCA 25/28 MI	5,2 ± 0,3	10,3 ± 0,2	5,2 ± 0,5	10,3 ± 0,3	4,00

### 5.4.3. Setting the air/gas ratio (Part load)




T001581-A

1. Unscrew the plug of the flue gas measurement point.
2. Connect the flue gas analyser.



**WARNING**

Ensure that the opening around the sensor is completely sealed when taking measurements.




C002271-F-04

3. In the main display, press key . The menu **EMMISSION MEASUREMENTS** is displayed on the screen.




If an automatic vent cycle is running, it is not possible to perform these operations.



C002346-D-04

4. Select the generator desired. The characteristics of the generator are displayed.




C002347-D-04

5. Turn the rotary button until **PMIN** is displayed. The part load is set.



If an automatic vent cycle is running, it is not possible to perform these operations.

6. Measure the percentage of O<sub>2</sub> or CO<sub>2</sub> in the flue gases (Front panel removed) .



7. If this rate does not match the required value, correct the gas/air ratio using the adjustment screw B on the gas valve unit.



- ▶ Turn the screw B anticlockwise to obtain a lower CO<sub>2</sub> value.
- ▶ Turn the screw B clockwise to obtain a higher CO<sub>2</sub> value.

8. Check the flame through the flame viewport.



The flame must be stable and blue in colour with orange particles around the edge of the burner.

O <sub>2</sub> /CO <sub>2</sub> control and setting values for gas H (G20) at low speed				
Boiler type	Setting value		Checking value	
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)
MCA 15	5,9 ± 0,4	8,4 ± 0,2	5,9 ± 0,4	8,4 ± 0,2
MCA 25	5,9 ± 0,4	8,4 ± 0,2	5,9 ± 0,4	8,4 ± 0,2
MCA 25/28 MI	5,9 ± 0,4	8,4 ± 0,2	5,9 ± 0,4	8,4 ± 0,2

O <sub>2</sub> /CO <sub>2</sub> control and setting values for gas L (G25) at low speed				
Boiler type	Setting value		Checking value	
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)
MCA 15	5,6 ± 0,4	8,4 ± 0,2	5,6 ± 0,4	8,4 ± 0,2
MCA 25	5,6 ± 0,4	8,4 ± 0,2	5,6 ± 0,4	8,4 ± 0,2
MCA 25/28 MI	5,6 ± 0,4	8,4 ± 0,2	5,6 ± 0,4	8,4 ± 0,2

O <sub>2</sub> /CO <sub>2</sub> control and setting values for propane (G31) at low speed				
Boiler type	Setting value		Checking value	
	O <sub>2</sub> (%)	CO <sub>2</sub> (%)	O <sub>2</sub> (%)	CO <sub>2</sub> (%)
MCA 15	5,8 ± 0,3	9,9 ± 0,2	5,8 ± 0,3	9,9 ± 0,2
MCA 25	5,8 ± 0,3	9,9 ± 0,2	5,8 ± 0,3	9,9 ± 0,2
MCA 25/28 MI	5,8 ± 0,3	9,9 ± 0,2	5,8 ± 0,3	9,9 ± 0,2




Repeat the high speed test and the low speed test as often as necessary until the correct values are obtained without having to make additional adjustments.

To exit the mode **EMISSION MEASUREMENTS**, press  $\square$  several times.



### 5.4.4. Basic setting for the gas/air ratio

If the gas/air ratio is out of adjustment, the gas valve unit has a basic setting. To do this, proceed as follows:





1. Switch off the boiler electrical power supply.
2. Close the gas valve on the boiler.
3. Remove the air inlet flue on the venturi.
4. Unscrew the top connection on the gas valve unit.
5. Disconnect the connector located under the fan.
6. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
7. Completely remove the fan/mixing elbow unit.
  - ☞ For steps 3 to 7 inclusive, see chapter: "Checking the burner and cleaning the heat exchanger", page 105
8. Turn the setting screw **A** on the gas valve unit to modify the position of the flow regulation valve.
9. Turn the setting screw **B** on the gas valve unit anticlockwise until it matches the front panel.
10. Turn the setting screw **B** on the gas valve unit by 6 turns clockwise.
11. Follow the procedure in reverse to re-assemble all of the components.

## 5.5 Checks and adjustments after commissioning

### 5.5.1. Displaying the parameters in extended mode

The display mode on the control panel is set as standard in such a way as only to show the "conventional" parameters. It is possible to switch to "extended" mode by proceeding as follows:



1. Access the "installer" level: Press key  for around 5 seconds.
2. Select the menu **#SYSTEM**.

- i**
  - ▶ Turn the rotary button to scroll through the menus or modify a value.
  - ▶ Press the rotary button to access the menu selected or confirm a value modification.

☞ For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62


3. Set the parameter **INSTALLATION** to **EXTENDED**.

"Installer" level - #SYSTEM menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
INSTALLATION	CLASSIC	Displays the parameters of a conventional installation	CLASSIC	
	EXTENDED	Displays all parameters		



Regardless of what is done to the keys, the regulator switches back to **CLASSIC** mode after 30 minutes.

### 5.5.2. Setting the parameters specific to the installation



C002235-F-04

1. Access the "installer" level: Press key **i** for around 5 seconds.
2. Select the menu **#SYSTEM**.



- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.



For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

3. Set the following parameters according to the connections made to the PCBs:

"Installer" level - #SYSTEM menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
CIRC. A: (1)(2)	DIRECT	Use as a direct heating circuit	DIRECT	
	PROGRAM.	Use as an independent programmable outlet		
	H.TEMP	Enables operation of circuit A in summer despite manual or automatic summer shutdown		
	DHW	Connection of a second domestic hot water tank		
	DHW ELEC	Used to control the electrical resistor according to the timer programme on circuit A in summer mode		
	DISAB.	No data for circuit A is displayed		
CIRC. B: (1)	3WV	Connecting a circuit with 3-way valve (For example: Underfloor heating)	3WV	
	SWIM.P.	Using the circuit for pool management		
	DIRECT	Use of circuit in direct heating circuit		
CIRC. C: (1)	3WV	Connecting a circuit with 3-way valve (For example: Underfloor heating)	3WV	
	SWIM.P.	Using the circuit for pool management		
	DIRECT	Use of circuit in direct heating circuit		


(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**  
 (2) If the pump incorporated in the boiler is used for circuit A (parameter **CIRC.A** set to **DIRECT**), the **O.PUMP A** outlet is free  
 (3) This parameter is displayed only if the **O.PUMP A** parameter is set to **CIRC.AUX** or if the 3-way valve PCB option is used


<b>"Installer" level - #SYSTEM menu</b>				
<b>Parameter</b>	<b>Adjustment range</b>	<b>Description</b>	<b>Factory setting</b>	<b>Customer setting</b>
<b>O.PUMP A</b> (1) (2)	<b>CH.PUMP A</b>	Heating pump circuit A: The <b>PUMP A</b> outlet is used to control the pump on circuit A	<b>CH.PUMP A</b>	
	<b>CIRC.AUX</b>	Used to resume the functions of the <b>S.AUX</b> parameter without adding the "PCB + sensor" option (Package AD249)		
	<b>DHW LOOP</b>	Used to control the domestic hot water looping pump according to the DHW timer programme and force its operation during an override		
	<b>PRIMARY PUMP</b>	The outlet <b>PUMP A</b> is active if a heating demand is present on the secondary pump		
	<b>ORDER BURNER</b>	The outlet <b>PUMP A</b> is active when a burner demand is present		
	<b>FAILURE</b>	The outlet <b>PUMP A</b> is active if an error is detected		
<b>O.DHW:</b> (1)	<b>PUMP</b>	Using a tank load pump on the DHW PUMP outlet	<b>RV</b>	
	<b>RV</b>	Use of a reversal valve for DHW production		
<b>S.AUX:</b> (1)(3)	<b>DHW LOOP</b>	Use as a domestic loop pump	<b>DHW LOOP</b>	
	<b>PROGRAM.</b>	Use as an independent programmable outlet		
	<b>PRIMARY PUMP</b>	The outlet <b>AUX PUMP</b> is active if a heating demand is present on the secondary pump		
	<b>ORDER BURNER</b>	The outlet <b>AUX PUMP</b> is active when a burner demand is present		
	<b>DHW</b>	Use of primary circuit of second DHW tank		
	<b>FAILURE</b>	The outlet <b>AUX PUMP</b> is active if an error is detected		
	<b>DHW ELEC</b>	Used to control the electrical resistor according to the timer programme on circuit AUX in summer mode		
<b>I.SYST</b> (1)	<b>SYSTEM</b>	The inlet sensor is used to connect the common flow sensor of a cascade system	<b>SYSTEM</b>	
	<b>STORAGE TANK</b>	Hot water storage tank affected to heating only		
	<b>DHW STRAT</b>	Using the DHW tank with 2 sensors (top and bottom)		
	<b>ST.TANK+DHW</b>	Hot water storage tank affected to heating and domestic hot water		
<b>O. TEL:</b> (1)	<b>FAILURE</b>	The telephone outlet is closed in the event of failure	<b>FAILURE</b>	
	<b>REVISION</b>	The telephone outlet is closed in the event of revision display		
	<b>DEF+REV</b>	The telephone outlet is closed in the event of failure or revision display		
<b>CT.TEL</b> (1)	<b>CLOSE</b>	See table below.	<b>CLOSE</b>	
	<b>OPEN</b>			
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b>				
(2) If the pump incorporated in the boiler is used for circuit A (parameter <b>CIRC.A</b> set to <b>DIRECT</b> ), the <b>O.PUMP A</b> outlet is free				
(3) This parameter is displayed only if the <b>O.PUMP A</b> parameter is set to <b>CIRC.AUX</b> or if the 3-way valve PCB option is used				

"Installer" level - #SYSTEM menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
<b>I.TEL:</b> (1)	<b>ANTIFR</b>	Start anti-freeze in boiler command	<b>ANTIFR</b>	
	<b>0/1 A</b>	ON or OFF contact: <b>I.TEL:</b> can be used as an antifreeze activation inlet on circuit A		
	<b>0/1 B</b>	ON or OFF contact: <b>I.TEL:</b> can be used as an antifreeze activation inlet on circuit B		
	<b>0/1 C</b>	ON or OFF contact: <b>I.TEL:</b> can be used as an antifreeze activation inlet on circuit C		
	<b>0/1 DHW</b>	ON or OFF contact: <b>I.TEL:</b> can be used as an antifreeze activation inlet on circuit ECS		
	<b>0/1 AUX</b>	ON or OFF contact: <b>I.TEL:</b> can be used as an antifreeze activation inlet on circuit AUX ( <b>S.AUX</b> if option *1 is present or outlet <b>O.PUMP A</b> is configured as <b>CIRC.AUX</b> ) When <b>I.TEL:</b> is not active, the auxiliary circuit (AUX) follows the maximum boiler temperature (parameter <b>BOILER MAX</b> ).		
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b> (2) If the pump incorporated in the boiler is used for circuit A (parameter <b>CIRC.A</b> set to <b>DIRECT</b> ), the <b>O.PUMP A</b> outlet is free (3) This parameter is displayed only if the <b>O.PUMP A</b> parameter is set to <b>CIRC.AUX</b> or if the 3-way valve PCB option is used				


Influence of the parameter setting CT.TEL on the I.TEL contact			
CT.TEL	I.TEL:	I.TEL contact closed	I.TEL contact open
<b>CLOSE</b>	<b>ANTIFR</b>	The antifreeze mode is active on all boiler circuits.	The mode selected on the boiler is active.
	<b>0/1 A</b>	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	<b>0/1 B</b>	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	<b>0/1 C</b>	The mode selected on the circuit is active.	The antifreeze mode is active on the circuit concerned.
	<b>0/1 DHW</b>	The mode selected on the DHW circuit is active.	The antifreeze mode is active for the DHW circuit.
	<b>0/1 AUX</b>	<ul style="list-style-type: none"> <li>▶ The <b>AUX</b> outlet on the connection terminal block is active.</li> <li>▶ The boiler operates at a set point temperature equal to <b>BOILER MAX</b>.</li> </ul>	<ul style="list-style-type: none"> <li>▶ The <b>AUX</b> outlet on the connection terminal block is not active.</li> <li>▶ The boiler operates with a set point temperature as a function of the outside temperature.</li> </ul>
<b>OPEN</b>	<b>ANTIFR</b>	The mode selected on the boiler is active.	The antifreeze mode is active on all boiler circuits.
	<b>0/1 A</b>	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	<b>0/1 B</b>	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	<b>0/1 C</b>	The antifreeze mode is active on the circuit concerned.	The mode selected on the circuit is active.
	<b>0/1 DHW</b>	The antifreeze mode is active for the DHW circuit.	The mode selected on the DHW circuit is active.
	<b>0/1 AUX</b>	<ul style="list-style-type: none"> <li>▶ The <b>AUX</b> outlet on the connection terminal block is not active.</li> <li>▶ The boiler operates with a set point temperature as a function of the outside temperature.</li> </ul>	<ul style="list-style-type: none"> <li>▶ The <b>AUX</b> outlet on the connection terminal block is active.</li> <li>▶ The boiler operates at a set point temperature equal to <b>BOILER MAX</b>.</li> </ul>

### 5.5.3. Naming the circuits and generators

1. Access the "installer" level: Press key  for around 5 seconds.
2. Select the menu **#NAMES OF THE CIRCUITS**.




C002235-F-04

- i** Turn the rotary button to scroll through the menus or modify a value.
  - Press the rotary button to access the menu selected or confirm a value modification.
-  For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

3. Select the circuit or generator you wish to rename.


"Installer" level - #NAMES OF THE CIRCUITS menu		
Parameter	Description	Name given by the customer
CIRC. A:	Circuit A	
CIRC. B:	Circuit B	
CIRC. C:	Circuit C	
CIRC.AUX	Auxiliary circuit	
CIRC.DHW	Domestic hot water circuit	
GENE	Generator	




C002344-C-04

4. Turn the rotary button to choose the first character from the list. To confirm, press the rotary button.
5. Then press again to enter a second character or turn the rotary button to leave an empty space.
6. Choose the other characters in the same way. The input zone may contain up to 7 characters.

**i** To move from one character to another, turn the rotary button. To exit without modifications, press key **ESC**.

7. To confirm the name, press the rotary button and then turn the button slightly anti-clockwise. When the symbol  appears, press the rotary button. The name is confirmed.

**i** If the name reaches 7 characters, it is automatically confirmed when the last character is confirmed.



C002345-C-04


### 5.5.4. Setting the heating curve


If an outside temperature sensor is connected, it is possible to adapt the heating curve.

1. Access the "installer" level: Press key  for around 5 seconds.
2. Select the menu **#SECONDARY INSTAL.P.**




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62





C002235-F-04

3. Select the parameter **HEAT.CURV. ....**



C002316-D-04

4. To modify the value directly, turn the rotary button.  
To modify the value by displaying the curve, press key .




C002317-D-04

5. To modify the curve, turn the rotary button.
6. To confirm, press the rotary button.  
To cancel, press key **ESC**.




**0.7** = Heating curve set



C002318-B-04

### ■ Heating curve without BCT

The BCT (Base heat Curve Temperature) allows a minimum operating temperature to be imposed on the heating circuit (this temperature may be constant if the circuit gradient is nil).




- ① Maximum temperature of the circuit
- ② Water temperature in the circuit for an outside temperature of 0°C
- ③ **DAY** set point on the circuit
- ④ Outside temperature for which the maximum water temperature in the circuit is reached
- ⑤ Value of the heating curve  
This value corresponds to the parameter **HEAT.CURV.**  
👉 See chapter: ""Professional" settings", page 82.



When you modify the heating curve, ② and ⑤ are recalculated and repositioned automatically.

### ■ Heating curve with BCT

The BCT (Base heat Curve Temperature) allows a minimum operating temperature to be imposed on the heating circuit (this temperature may be constant if the circuit gradient is nil).




- ① Maximum temperature of the circuit
- ② Water temperature in the circuit for an outside temperature of 0°C
- ③ **DAY** set point on the circuit
- ④ Outside temperature for which the maximum water temperature in the circuit is reached
- ⑤ Value of the heating curve  
This value corresponds to the parameter **HEAT.CURV.**  
👉 See chapter: ""Professional" settings", page 82.
- x Value set to the parameter **HCZP D**



When you modify the heating curve, ② and ⑤ are recalculated and repositioned automatically.

### 5.5.5. Finalizing work




1. Remove the measuring equipment.
2. Put the flue gas sampling plug back in place.
3. Refit the front panel. Tighten the two screws by a quarter turn.
4. Raise the temperature in the heating system to approximately 70°C.
5. Shut down the boiler.
6. After about 10 minutes, vent the air in the heating system.
7. Checking the hydraulic pressure. If necessary, top up the water level in the heating system (recommended hydraulic pressure between 1,5 and 2 bar).
8. Tick the gas category used on the data plate.
9. Complete the checklist.
10. Explain the operation of the installation, the boiler and the regulator to the users.
11. Inform the user of the periodicity of maintenance work to be carried out. Input the service date and the contact details of the installer.
  - ☞ See chapter: "Customising maintenance", page 99.
12. Give all the instruction manuals to the user.

Commissioning of the boiler is now complete.

**i** The various boiler parameters are preset in the factory. These factory settings are suitable for the most common heating systems. For other systems and situations, the parameters can be modified.

### 5.6 Reading out measured values

The various values measured by the appliance are displayed in the **#MEASURES** menu.



1. To access "user" level: Press the → key.
2. To select the **#MEASURES** menu.

**i**

- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

☞ For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62.

"User" level - #MEASURES menu		
Parameter	Description	Unit
<b>OUTSIDE TEMP.</b>	Outside temperature	°C
<b>ROOMTEMP. A</b> <sup>(1)</sup>	Room temperature of circuit A	°C
<b>ROOMTEMP. B</b> <sup>(1)</sup>	Room temperature of circuit B	°C
<b>ROOMTEMP. C</b> <sup>(1)</sup>	Room temperature of circuit C	°C

(1) The parameter is only displayed for the options, circuits or sensors actually connected.  
 (2) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**.



"User" level - #MEASURES menu		
Parameter	Description	Unit
<b>BOILER TEMP.</b>	Water temperature in the boiler	°C
<b>PRESSURE</b>	Water pressure in the installation	bar
<b>WATER TEMP.</b> <sup>(1)</sup>	Water temperature in the DHW tank	°C
<b>STOR.TANK.TEMP</b> <sup>(1)</sup>	Water temperature in the storage tank	°C
<b>SWIMMING P.T.B</b> <sup>(1)</sup>	Water temperature of the swimming pool on circuit B	°C
<b>SWIMMING P.T.C</b> <sup>(1)</sup>	Water temperature of the swimming pool on circuit C	°C
<b>OUTLET TEMP. B</b> <sup>(1)</sup> <sup>(2)</sup>	Temperature of the flow water in circuit B	°C
<b>OUTLET TEMP. C</b> <sup>(1)</sup> <sup>(2)</sup>	Temperature of the flow water in circuit C	°C
<b>SYSTEM TEMP.</b> <sup>(1)(2)</sup>	Temperature of the system flow water if multi-generator	°C
<b>T.DHW BOTTOM</b> <sup>(2)</sup>	Water temperature in the bottom of the DHW tank	°C
<b>TEMP.TANK AUX</b> <sup>(1)</sup> <sup>(2)</sup>	Water temperature in the second DHW tank connected to the AUX circuit	°C
<b>DHW A TEMP.</b> <sup>(1)(2)</sup>	Water temperature in the second DHW tank connected to circuit A	°C
<b>BACK TEMP</b> <sup>(2)</sup>	Temperature of the boiler return water	°C
<b>WIND SPEED</b> <sup>(2)</sup>	Fan rotation speed	rpm
<b>POWER</b> <sup>(2)</sup>	Instantaneous boiler output (0%: Burner off or running at minimum output)	%
<b>CURRENT</b> (μA) <sup>(2)</sup>	Ionization current	μA
<b>NB IMPULS.</b> <sup>(2)</sup>	Number of burner start-ups (not restartable) The meter is incremented by 8 every 8 start-ups	
<b>RUNTIME</b> <sup>(2)</sup>	Number of burner operation hours (not restartable) The meter is incremented by 2 every 2 hours	h
<b>IN 0-10V</b> <sup>(1)(2)</sup>	Voltage at input 0-10 V	V
<b>CTRL</b> <sup>(2)</sup>	Software control number	
<sup>(1)</sup> The parameter is only displayed for the options, circuits or sensors actually connected. <sup>(2)</sup> The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b> .		


## 5.7 Changing the settings

The boiler control panel is set for the most common heating systems. With these settings, practically all heating systems operate correctly. The user or installer can optimise the parameters according to own preferences.




For the "user" settings, refer to the user instructions.

### 5.7.1. Language selection




C002235-F-04

1. Access the "installer" level: Press key  for around 5 seconds.
2. Select the menu **#LANGUAGE**.




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.


 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

"Installer" level - #LANGUAGE menu		
Adjustment range	Description	Factory setting
FRANCAIS	Display in French	FRANCAIS
DEUTSCH	Display in German	
ENGLISH	Display in English	
ITALIANO	Display in Italian	
ESPANOL	Display in Spanish	
NEDERLANDS	Display in Dutch	
РУССКИЙ	Display in Russian	
POLSKY	Display in Polish	
TÜRK	Display in Turkish	

### 5.7.2. Calibrating the sensors




C002219-D-04


1. To access "user" level: Press the  key.
2. To select the **#SETTING** menu.




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

3. To set the following parameters:

<b>"User" level - #SETTING menu</b>				
<b>Parameter</b>	<b>Adjustment range</b>	<b>Description</b>	<b>Factory setting</b>	<b>Customer setting</b>
<b>SUM/WIN</b>	15 to 30 °C	Used to set the outside temperature above which heating will be shut down. <ul style="list-style-type: none"> <li>▶ The heating pumps are shut down.</li> <li>▶ The burner will only start for domestic hot water needs.</li> <li>▶ The letter <b>E</b> and the symbol  are displayed.</li> </ul>	22 °C	
	<b>NO</b>	Heating is never shut down automatically		
<b>CALIBR. OUT</b>		Outside sensor calibration: Used to correct the outside temperature	Outside temperature	
<b>CALIBR. ROOM A</b> (1)		Calibration of the room sensor on circuit A: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit A	
<b>OFFSET ROOM A</b> (2)	-5.0 to +5.0 °C	Room offset on circuit A: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
<b>ANTIFR. ROOM A</b>	0.5 to 20 °C	Room temperature antifreeze activation on circuit A	6 °C	
<b>CALIBR. ROOM B</b> (1)(3)		Calibration of the room sensor on circuit B: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit B	
<b>OFFSET ROOM B</b> (2)(3)	-5.0 to +5.0 °C	Room offset on circuit B: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
<b>ANTIFR. ROOM B</b> (3)	0.5 to 20 °C	Room temperature at which the antifreeze mode is activated on circuit B	6 °C	
<b>CALIBR. ROOM C</b> (1)(3)		Calibration of the room sensor on circuit C: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	Room temperature of circuit C	
<b>OFFSET ROOM C</b> (2)(3)	-5.0 to +5.0 °C	Room offset on circuit C: Is used to set a room offset Make this setting 2 hours after switching on, when the room temperature has stabilised	0.0	
<b>ANTIFR. ROOM C</b> (3)	0.5 to 20 °C	Room temperature antifreeze activation on circuit C	6 °C	
<p>(1) The parameter is only displayed if a room sensor is connected to the circuit concerned</p> <p>(2) The parameter is only displayed if no room sensors are connected to the circuit concerned</p> <p>(3) The parameter is only displayed if the circuit concerned is actually connected</p>				

### 5.7.3. "Professional" settings



C002235-F-04

1. Access the "installer" level: Press key for around 5 seconds.
2. To set the following parameters:

- Turn the rotary button to scroll through the menus or modify a value.
  - Press the rotary button to access the menu selected or confirm a value modification.
- For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

"Installer" level - #PRIMARY LIMITS menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
<b>BOILER MAX</b>	20 to 90 °C	Maximum boiler temperature	75 °C	
<b>MAX.R.HEAT(%)</b> <sup>(1)</sup>	0-100%	Maximum boiler output during heating	100%	
<b>MAX.DHW(%)</b> <sup>(1)(2)</sup>	0-100%	Maximum boiler output in DHW	100%	
<b>MIN.VENT.</b> <sup>(1)</sup>	1000-5000 rpm	Minimum fan speed	See table below	
<b>MAX.VENT.BOIL</b> <sup>(1)</sup>	1000-7000 rpm	Maximum fan speed setting in heating	See table below	
<b>MAX.VENT.DHW</b> <sup>(1)</sup>	1000-7000 rpm	Maximum fan speed setting in domestic hot water	See table below	
<b>START SP.</b> <sup>(1)</sup>	1000-5000 rpm	Optimum start-up speed setting	See table below	
<b>MAX.PUMP SPEED</b> <sup>(1)</sup>	20-100%	Maximum pump speed	See table below	
<b>MIN.PUMP SPEED</b> <sup>(1)</sup>	20-100%	Minimum pump speed	See table below	

(1) The parameter is only displayed if **INSTALLATION** parameter is set to **EXTENDED**  
 (2) The parameter is only displayed if **P.DHW** is set to **PUMP**

Type of gas used	Parameter	Unit	MCA 15	MCA 25	MCA 25/28 MI
Gas H (G20)	<b>MIN.VENT.</b>	rpm	1800	1800	1800
	<b>MAX.VENT.BOIL</b>	rpm	4500	5600	4600
	<b>MAX.VENT.DHW</b>	rpm	4500	5600	6200
	<b>START SP.</b>	rpm	3700	3000	3000
Gas L (G25)	<b>MIN.VENT.</b>	rpm	1800	1800	1800
	<b>MAX.VENT.BOIL</b>	rpm	4400	5300	4300
	<b>MAX.VENT.DHW</b>	rpm	4400	5300	5900
	<b>START SP.</b>	rpm	3700	3000	3000
Propane (G31)	<b>MIN.VENT.</b>	rpm	2200	1800	1800
	<b>MAX.VENT.BOIL</b>	rpm	4400	5300	4300
	<b>MAX.VENT.DHW</b>	rpm	4400	5300	5900
	<b>START SP.</b>	rpm	3700	3000	3000

"Installer" level - #SECONDARY LIMITS menu			
Parameter	Adjustment range	Description	Factory setting
<b>MAX.CIRC.A</b>	20 to 95 °C	Maximum temperature (Circuit A) See comments below	75 °C
<b>MAX.CIRC.B</b>	20 to 95 °C	Maximum temperature (Circuit B) See comments below	50 °C
<b>MAX.CIRC.C</b>	20 to 95 °C	Maximum temperature (Circuit C) See comments below	50 °C
<b>OUT.ANTIFREEZE</b>	<b>OFF</b> , -8 to +10 °C	Outside temperature at which the installation's antifreeze protection is activated. Below this temperature the pumps are permanently on and the minimum temperatures for each circuit are respected. When <b>NIGHT : STOP</b> is set, the reduced temperature is maintained in each circuit (#SECONDARY INSTAL.P menu). <b>OFF</b> : Antifreeze protection is not activated	+3 °C
<b>HCZP D A</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit A)	<b>OFF</b>
<b>HCZP N A</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit A)	<b>OFF</b>
<b>HCZP D B</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit B)	<b>OFF</b>
<b>HCZP N B</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit B)	<b>OFF</b>
<b>HCZP D C</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Daytime mode (Circuit C)	<b>OFF</b>
<b>HCZP N C</b> (1)(2)	<b>OFF</b> , 20 to 90 °C	Curve base temperature in Nighttime mode (Circuit C)	<b>OFF</b>
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b>			
(2) The parameter can be set to the heating curve by pressing key $\uparrow$ .			

"Installer" level - #PRIMARY INSTAL.P menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
<b>BURN.MIN.RUN</b> (1)(2)	0 to 180 seconds	Setting the burner minimum operation time (In heating mode)	30 seconds	
<b>TIMER GENE P.</b> (2)	1 to 30 minutes	Maximum post-operation duration of the generator pump	4 minutes	
<b>IN.BL</b> (2)	<b>STOP HEAT</b>	Configuration of the PCU BL inlet If the contact is open, the heating is off. If the parameter <b>P.DHW</b> is set to VI, DHW production nevertheless remains functional. Automatic restart when the contact closes.	<b>TOTAL STOP</b>	
	<b>TOTAL STOP</b>	Configuration of the PCU BL inlet If the contact is open, heating and DHW production are off. Automatic restart when the contact closes.		
	<b>SAFETY MODE</b>	Configuration of the PCU BL inlet If the contact is open, the boiler goes into safety lockout. The boiler needs to be reset to restart.		
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b>				
(2) The parameter can be set to the heating curve by pressing key $\uparrow$ .				


<b>"Installer" level - #SECONDARY INSTAL.P menu</b>				
<b>Parameter</b>	<b>Adjustment range</b>	<b>Description</b>	<b>Factory setting</b>	<b>Customer setting</b>
<b>BUILD. INERTIA</b> <sup>(1)(3)</sup>	0 (10 hours) to 10 (50 hours)	Characterisation of building's inertia: 0 for a building with low thermal inertia. 3 for a building with normal thermal inertia. 10 for a building with high thermal inertia. <b>Modification of the factory setting is only useful in exceptional cases.</b>	3 (22 hours)	
<b>CIRC.CURVE A</b>	0 to 4	Heating curve of the circuit A See comments below	1.5	
<b>ROOM INFL. A</b>	0 to 10	Influence of room sensor A See comments below	3	
<b>CIRC.CURVE B</b>	0 to 4	Heating curve of the circuit B See comments below	0.7	
<b>ROOM INFL. B</b>	0 to 10	Influence of room sensor B See comments below	3	
<b>CIRC.CURVE C</b>	0 to 4	Heating curve of the circuit C See comments below	0.7	
<b>ROOM INFL. C</b>	0 to 10	Influence of room sensor C See comments below	3	
<b>SCREED DRYING</b>	<b>NO, B, C, B+C</b>	Drying the floor See comments below	<b>NO</b>	
<b>START DRYING TEMP</b> <sup>(2)</sup>	20 to 50 °C	Scree drying start temperature	20 °C	
<b>STOP DRYING TEMP</b> <sup>(2)</sup>	20 to 50 °C	Scree drying stop temperature	20 °C	
<b>NUMB. DAYS DRY</b> <sup>(2)</sup>	0 to 99		0	
<b>NIGHT</b>	<b>DEC.</b>	The lower temperature is maintained (Night mode) See comments below	<b>DEC.</b>	
	<b>STOP</b>	The boiler is stopped (Night mode) See comments below		
<b>IN 0-10V</b>	<b>OFF / ON</b>	Activating the control at 0-10 V See comments below	<b>OFF</b>	
<b>VMIN/OFF 0-10V</b> <sup>(3)</sup>	0 to 10 V	Voltage corresponding to the instruction set minimum	0.5 V	
<b>VMAX 0-10V</b> <sup>(3)</sup>	0 to 10 V	Voltage corresponding to the instruction set maximum	9.5 V	
<b>CONS.MIN 0-10V</b> <sup>(3)</sup>	10 to 70 °C	Instruction minimum set temperature	20 °C	
<b>CONS.MAX 0-10V</b> <sup>(3)</sup>	10 to 100 °C	Maximum set temperature	80 °C	
<b>BAND WIDTH</b>	4 to 16 K	Control unit bandwidth for the 3-way valves. Option of increasing the bandwidth if the valves are rapid or of reducing it if they are slow.	<b>12 K</b>	
<b>BOIL/3WV SHIFT</b>	0 to 16 K	Minimum temperature difference between the boiler and the valves	<b>4 K</b>	
<b>H. PUMP DELAY</b>	0 to 15 minutes	Timing of the shutdown of the heating pumps. The timing of heating pump shutdown prevents the boiler overheating.	<b>4 minutes</b>	
<p>(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b></p> <p>(2) The parameter is only displayed if <b>SCREED DRYING</b> is other than <b>OFF</b></p> <p>(3) The parameter is only displayed if <b>IN 0-10V</b> is set to <b>ON</b>.</p> <p>(4) If a reversal valve is connected, DHW priority will always be total regardless of the setting.</p>				

"Installer" level - #SECONDARY INSTAL.P menu				
Parameter	Adjustment range	Description	Factory setting	Customer setting
<b>HW. PUMP DELAY</b>	0 to 15 minutes	Timing of the shutdown of the domestic hot water pump. The timing of the domestic hot water load pump shutdown prevents the boiler and the heating circuits overheating (Only if a load pump is used).	<b>2 minutes</b>	
<b>ADAPT</b>	<b>ON</b>	Automatic adaptation of the heating curves for each circuit with a room sensor with an influence of >0.	<b>ON</b>	
	<b>OFF</b>	The heating curves can only be modified manually.		
<b>PRIORITY DHW<sup>(4)</sup></b>	<b>TOTAL</b>	Interruption of pool heating and reheating during domestic hot water production.	<b>TOTAL</b>	
	<b>SLIDING</b>	Domestic hot water production and heating on the valve circuits if the available output is sufficient and the hydraulic connection allows.		
	<b>NO</b>	Heating and domestic hot water production in parallel if the hydraulic connection allows. ⚠ Risk of overheating in the direct circuit.		
<b>PRIM.TEMP.DHW</b>	50 to 90 °C	Boiler temperature setting if producing domestic hot water	75 °C	
<b>LEG PROTEC</b>		The "anti legionella" function acts to prevent the development of legionella in the dhw tank, these bacteria are responsible for legionellosis.	<b>OFF</b>	
	<b>OFF</b>	Anti-legionella function not activated		
	<b>DAILY</b>	The tank is overheated every day from 4:00 o'clock to 5:00 o'clock		
	<b>WEEKLY</b>	The tank is overheated every Saturday from 4:00 o'clock to 5:00 o'clock		
(1) The parameter is only displayed if <b>INSTALLATION</b> parameter is set to <b>EXTENDED</b> (2) The parameter is only displayed if <b>SCREED DRYING</b> is other than <b>OFF</b> (3) The parameter is only displayed if <b>IN 0-10V</b> is set to <b>ON</b> . (4) If a reversal valve is connected, DHW priority will always be total regardless of the setting.				

■ **MAX.CIRC...**

■ **CIRC. CURVE ...**

**Heating curve circuit A, B or C**



- x** Outside temperature (°C)
- y** Water flow temperature (°C)
- ① Maximum temperature of the circuit B - C


### ■ SCREED DRYING

Used to force a constant flow temperature or a train to accelerate screed drying on underfloor heating.


The setting for these temperatures must follow the screed-layer's recommendations.

Activation of this parameter (setting other than **OFF**) forces the permanent display of **SCREED DRYING** and deactivates all other control system functions.

When floor drying is active on a circuit, all other circuits (e.g. DHW) are shut down. The use of this function is only possible on circuits B and C.



- ① **STOP DRYING TEMP**
- ② **START DRYING TEMP**
- ③ Today
- ④ **NUMB. DAYS DRY.**
- ⑤ Normal regulation (End of drying)
- ⑥ Heating temperature setting (°C)



- For example**
- ① **STOP DRYING TEMP: 47 °C**
  - ② **START DRYING TEMP: 20 °C**
  - ④ **NUMB. DAYS DRY.**
  - ⑤ Normal regulation (End of drying)
  - ⑥ Heating temperature setting (°C)
- i** Every day at midnight (00:00): the set point (**START DRYING TEMP**) is recalculated and the remaining number of days (**NB DAYS DRYING**) is decremented.

### ■ ROOM S.INFL

Used to adjust the influence of the room sensor on the water temperature for the circuit concerned.

0	No influence (remote control fitted in a location with no influence)
1	Slight influence
3	Average influence (recommended)
10	Room thermostat type operation



■ NIGHT



This parameter is displayed if at least one circuit does not include a room sensor.

**For circuits without a room sensor:**


- ▶ **NIGHT :DEC.** (Reduced): The reduced temperature is maintained during reduced periods. The circuit pump operates constantly.
- ▶ **NIGHT :STOP** (Stop): Heating is shut down during reduced periods. When installation antifreeze is active, the reduced temperature is maintained during reduced periods.

**For circuits with a room sensor:**

- ▶ When the room temperature is lower than the room sensor set point: The reduced temperature is maintained during reduced periods. The circuit pump operates constantly.
- ▶ When the room temperature is higher than the room sensor set point: Heating is shut down during reduced periods. When installation antifreeze is active, the reduced temperature is maintained during reduced periods.

■ Function 0-10 V


This function controls the boiler using an external system that includes a 0-10 V output connected to the 0-10 V input. This control imposes an instruction set temperature on the boiler. It will be necessary to ensure that the parameter **BOILER MAX** is higher than **CONS.MAX 0-10V**.




- 1 Instruction set outlet temperature (°C)
- 2 Power input signal (V) - DC
- 3 0 V
- 4 **CONS.MIN 0-10V**
- 5 **CONS.MAX 0-10V**
- 6 **VMIN/OFF 0-10V**
- 7 **VMAX 0-10V**
- 8 10 V
- x Voltage at input
- y Boiler temperature

If the input voltage is less than **VMIN/OFF 0-10V**, the boiler is off. The boiler temperature setting corresponds strictly to the 0-10 V input. The secondary boiler circuits continue to operate but have no impact on the water temperature in the boiler. If using the 0-10 V input and a secondary boiler circuit, the external regulator providing this 0-10 V power supply must always request a temperature at least equal to the needs of the secondary circuit.

### 5.7.4. Configuring the network



C002235-F-04

1. Access the "installer" level: Press key  for around 5 seconds.
2. Select the menu **#NETWORK**.



- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.



For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

3. To set the following parameters:


"Installer" level - #NETWORK menu <sup>(1)</sup>				
Parameter	Adjustment range	Description	Factory setting	Customer setting
<b>CASCADE:</b>	ON / NO	ON: System in cascade	NO	
<b>MASTER CONTROLLER</b> <sup>(2)</sup>	ON / NO	Configure this control system as master on the bus	ON	
<b>SYSTEM NETWORK</b> <sup>(3)</sup>		Specific menu: Enlist generators or VMs in cascade mode (See following chapter: "Connecting appliances in cascade")		
<b>FUNCT</b> <sup>(3)</sup>	<b>CLASSIC</b>	Operation in cascade: Successive triggering of the various boilers in the cascade according to requirements	<b>CLASSIC</b>	
	<b>PARALLEL</b>	Functioning in parallel cascade: If the outside temperature is lower than the value <b>PARALLEL.CASC</b> , all of the boilers are started up at the same time		
<b>PARALLEL CASC.</b> <sup>(4)</sup>	-10 to 20 °C	Outside temperature triggering all stages in parallel mode	10 °C	
<b>INTER STAGE TIMER</b> <sup>(2)</sup>	1 to 30 min	Time delay for starting up or shutting down generators.	4 mn	
<b>SLAVE NUMBER</b> <sup>(5)</sup>	2 to 10	Set the network address of the secondary generator	2	
<b>3WW PLC</b>		Specific menu (Not used)		
<b>InOne SCENARIO</b>		Specific menu: Configure the InOne scenarios to be managed by the SCU PCB (See following chapter: "Configuring the scenarios")		
<b>REMOVE DEVICE</b>		Specific menu: see below		

(1) The menu is displayed only if the **INSTALLATION** parameter is set to **EXTENDED**  
 (2) The parameter is only displayed if **CASCADE** is set to **YES**  
 (3) The parameter is displayed only if **MASTER CONTROLLER** is set to **YES**  
 (4) The parameter is only displayed if **FUNCT** is set to **PARALLEL**  
 (5) The parameter is displayed only if **MASTER CONTROLLER** is set to **OFF**


### ■ Connecting appliances in cascade

It is possible, in a cascade configuration, to enlist generators and/or VMs as slaves. Proceed as follows:


1. Set **CASCADE** to **YES** by pressing the rotary button and then turning and pressing it again to confirm.
2. Select **SYSTEM NETWORK** and press the rotary button to go to the specific menu.




3. To add a slave appliance to the network, select **ADD SLAVE**.




4. The screen displayed allows you to choose numbers for the slave boilers to be added to the network. Numbers 2 to 10 are dedicated to the generators and numbers 20 to 39 to the VM. Turn the rotary button to scroll through the numbers and press to confirm the number chosen. Press  to go back to the previous list.



5. To remove a slave appliance from the network, select **ERASE NETWORK**.



6. The screen displayed allows you to choose the numbers of the slave boilers to be removed from the network. Turn the rotary button to scroll through the numbers and press to remove the number chosen. Press  to go back to the previous list.




7. Select **NUMB.ELEMENTS.NETWORK**. This screen summarises the elements in the network recognised by the system. Press  $\square$  to go back to the previous list.


### ■ Configuring the scenarios

It is possible to choose a scenario and allocate it to various IOBL units via the carrier current. Proceed as follows:


1. In the menu **#NETWORK**, select **InOne SCENARIO**.



2. Choose a number to allocate to the scenario by turning the rotary button; up to 4 scenarios can be saved. To confirm, press the rotary button.




3. Choose the desired scenario by turning the rotary button and then confirm.



Scenarios available	Description
<b>HOLIDAYS ON</b>	Holiday mode active (all circuits)
<b>HOLIDAYS OFF</b>	Holiday mode inactive (all circuits)
<b>OUT.AUX ON</b>	Aux outlet enabled
<b>OUT.AUX OFF</b>	Aux outlet disabled
<b>DHW DAY</b>	DHW in day mode
<b>DHW NIGHT</b>	DHW in night mode
<b>DEFAULT ON</b>	Default active
<b>DEFAULT OFF</b>	No active default
<b>INPUT TEL.ON</b>	Telephone input active
<b>INPUT TEL.OFF</b>	Telephone input not active


4. Enlist the various InOne units that have to abide by the scenario and confirm by pressing the rotary button.




## ■ Removing a device

To remove a device, proceed as follows:

1. In the menu **#NETWORK**, select **REMOVE DEVICE**.




2. Choose the device to be removed by turning the rotary button and pressing to confirm.




## ■ Controlling the boiler from an IOBL Scenario Switch

It is possible to control the boiler from a scenario switch (the boiler is then considered a slave boiler). Proceed as follows:

1. Remove the cover from the IOBL scenario switch to access the LEARN key.




C002421-B



C002422-B-04

2. Press the LEARN key and the control key used to pilot the scenario. A pairing signal is sent to the boiler by carrier current, which displays the following message on the control panel: "A device is trying to connect, do you want to allow this?"

- Set the display to **YES** by turning the rotary button and pressing to confirm.




- Choose the circuit used to run the scenario by turning the rotary button and pressing to confirm.




**CAUTION**

If one of the SCU PCBs is not correctly paired, the following message appears:  
 "NB not all of the SCUs are recognised".  
 Start the pairing procedure again.



- Choose the desired scenario by turning the rotary button and then confirm.



Scenarios available	Description
<b>AUTO</b>	Heating according to the time programme
<b>DAY</b>	Comfort mode
<b>NIGHT</b>	Reduced mode
<b>HOLIDAYS</b>	Holiday mode
P1	Programme P1 chosen
P2	Programme P2 chosen
P3	Programme P3 chosen
P4	Programme P4 chosen


- Terminate pairing by pressing the LEARN key on the IOBL scenario switch.




## ■ Erasing a scenario from the IOBL Scenario Switch

It is possible to remove a scenario using the IOBL scenario switch. Proceed as follows:

1. Press the LEARN key on the scenario switch, then the control key that pilots the scenario to be erased. A message asking whether you wish to erase the scenario is displayed on the control panel interface.
2. Set the display to **YES** by turning the rotary button and pressing to confirm.






3. Confirm removal by pressing the LEARN key on the IOBL scenario switch.



### 5.7.5. Returning to the factory settings


To reset the appliance, proceed as follows:

1. Press key ↓, → and ↻ simultaneously for 4 seconds. The menu #RESET is displayed.



2. Select the generator desired.
3. To set the following parameters:

#RESET menu			
Choice of generator	Parameter		Description
GENERATOR	RESET	TOTAL	Performs a TOTAL RESET of all parameters
		EXCEPT PROG.	Performs a parameter RESET but retains the timer programmes
		PROG.	Performs a RESET on the timer programmes but retains the parameters
		IOBL	Resets the system's network connections
		SENSOR SCU	Performs a RESET of the generator sensors connected
		ROOM SENSOR	Performs a RESET of the room sensors connected



After reset (**TOTAL RESET** and **RESET EXCEPT PROG.**), the control system goes back to the display of the language choice after a few seconds.

1. Select the desired language by turning the rotary button.
2. To confirm, press the rotary button.

## 6 Switching off the appliance

### 6.1 Installation shutdown



#### CAUTION

Do not switch off the boiler. If the central heating system is not used for a long period, we recommend activating the **HOLIDAYS** mode.

### 6.2 Frost protection

When the heating water temperature in the boiler falls by too much, the integrated protection system in the boiler starts up. This protection functions as follows:

- ▶ If the water temperature is lower than 7°C, the heating pump starts up.
- ▶ If the water temperature is lower than 4°C, the boiler starts up.
- ▶ If the water temperature is higher than 10°C, the boiler shuts down and the heating pump continues to run for a short time.



#### CAUTION

- ▶ The antifreeze protection does not function if the boiler is switched off.
- ▶ The integrated protection system only protects the boiler, not the installation. To protect the installation, set the appliance to **HOLIDAYS** mode.

The **HOLIDAYS** mode protects:

- ▶ The installation if the outside temperature is lower than 3°C (factory setting).
- ▶ The room temperature if a remote control is connected and the room temperature is lower than 6 °C (factory setting).
- ▶ The domestic hot water tank if the tank temperature is lower than 4 °C (the water is reheated to 10 °C).

To configure the holidays mode:  Refer to the user instructions.

# 7 Checking and maintenance

## 7.1 General instructions



### WARNING

- ▶ Maintenance operations must be done by a qualified engineer.
- ▶ An annual inspection is compulsory.
- ▶ Only original spare parts must be used.

- ▶ Have the flues swept **at least once a year** or more, depending on the regulations in force in your country.
  - ▶ See chapter: "Chimney sweep instructions", page 98
- ▶ Carry out the inspection and standard maintenance operations once a year.
  - ▶ See chapter: "Standard inspection and maintenance operations", page 100
- ▶ Carry out specific maintenance operations if necessary.
  - ▶ See chapter: "Specific maintenance operations", page 106

## 7.2 Chimney sweep instructions



### CAUTION

Have the flues swept **at least once a year** or more, depending on the regulations in force in your country. Only a qualified engineer may carry out the following operations.


1. Press the key.
2. Check the combustion each time the flues are swept. See chapter: "Setting the air/gas ratio (Full load)", page 67 + "Setting the air/gas ratio (Part load)", page 69
3. To go back to the main display, press key 2 times.

EMISSION MEASUREMENTS menu				
Generator	Function available	Description	Values displayed	
Generator name	OFF	normal operation	BOILER TEMP.	°C
			CURRENT	µA
			WIND SPEED	rpm
			BACK TEMP	°C
	PMIN	Operating at minimum output	BOILER TEMP.	°C
			CURRENT	µA
			WIND SPEED	rpm
			BACK TEMP	°C
	PMAX	Operating at maximum output	BOILER TEMP.	°C
			CURRENT	µA
			WIND SPEED	rpm
			BACK TEMP	°C

### 7.3 Customising maintenance


#### 7.3.1. Maintenance message

The boiler incorporates a function that can be used to display a maintenance message. To set the parameters for this function, proceed as follows:


1. Access the "After Sales" level: Hold key  down until **#PARAMETERS** is displayed.
2. Select the menu **#REVISION**.



- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62

3. To set the following parameters:



C002272-C-04

"After Sales" level - #REVISION menu		
Parameter	Adjustment range	Description
TYPE	NO	Factory setting No message indicating that maintenance is necessary
	MANU	Recommended setting Signals that maintenance is necessary on the date selected. Set the date using the parameters below.
	AUTO	<b>⚠</b> Not applicable. Do not select this setting.
REVISION HOUR <sup>(1)</sup>	0 to 23	Time at which the <b>REVISION</b> display appears
REV. YEAR <sup>(1)</sup>	2008 to 2099	Year in which the <b>REVISION</b> display appears
REVIS. MONTH <sup>(1)</sup>	1 to 12	Month in which the <b>REVISION</b> display appears
REVISION DATE <sup>(1)</sup>	1 to 31	Day on which the <b>REVISION</b> display appears

(1) The parameter is only displayed if **MANU** is configured.

### ■ Clearing the maintenance message

After carrying out the maintenance operations, modify the date in the **#NETWORK** menu to clear the message.

### ■ In the event of maintenance before the maintenance message is displayed

After carrying out early maintenance operations, it is necessary to set a new date in the **#NETWORK** menu.


### 7.3.2. Installer's contact details

To call up the installer's telephone number when maintenance is necessary, proceed as follows:

1. Access the "After Sales" level: Hold key  down until **#PARAMETERS** is displayed.
2. Select the menu **#SUPPORT**.




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62


3. To set the following parameters:

"After Sales" level - #SUPPORT menu	
Parameter	Description
<b>NAME</b>	Input the installer's name
<b>TELEPHONE NUM.</b>	Input the installer's telephone number

When the message, **REVISION**, is displayed, press ? to display the installer's telephone number.



C002272-C-04



C002302-D-04

## 7.4 Standard inspection and maintenance operations



### CAUTION

During inspection and maintenance operations, always replace all gaskets on the parts removed.

### 7.4.1. Checking the hydraulic pressure

---

The hydraulic pressure must reach a minimum of 0,8 bar. If the hydraulic pressure is lower than 0,8 bar, the symbol **bar** flashes.



If necessary, top up the water level in the heating system (recommended hydraulic pressure between 1,5 and 2 bar).

### 7.4.2. Checking the opened expansion vessel

---

Check the opened expansion vessel and replace it if necessary.

### 7.4.3. Checking the ionisation current

---

The ionisation current is displayed in the menu **#MEASURES**.



See chapter: "Reading out measured values", page 78

### 7.4.4. Checking the transfer capacity

---

If the transfer capacity is noticeably low (temperature too low and/or flow rate less than 6,2 l/min), clean the plate exchanger (domestic hot water end) and the water filter cartridge.




See chapter: "Cleaning the plate exchanger (domestic hot water end) and the water filter cartridge", page 106

### 7.4.5. Checking the tightness of the combusted gases evacuation and air inlet connections


---

Check the tightness of the connection for the evacuation of combustion gases and the air inlet.



T001580-A

### 7.4.6. Checking combustion



T001581-A



The check on combustion is done by measuring the percentage of  $O_2/CO_2$  in the flue gas discharge flue. To do this, proceed as follows:

1. Unscrew the plug of the flue gas measurement point.
2. Connect the flue gas analyser.



#### CAUTION


Ensure that the opening around the sensor is completely sealed when taking measurements.

3. Set the boiler to full load.  See chapter: "Setting the air/gas ratio (Full load)", page 67. The boiler is now operating at full load. Measure the percentage of  $CO_2$  and compare this value with the checking values given.
4. Set the boiler to part load.  See chapter: "Setting the air/gas ratio (Part load)", page 69. The boiler is now operating on part load. Measure the percentage of  $CO_2$  and compare this value with the checking values given.




### 7.4.7. Checking the automatic air vent


1. Switch off the boiler electrical power supply.
2. Close the gas valve on the boiler.
3. Close the main gas inlet valve.
4. Unscrew the two screws located under the front panel by a quarter turn and remove the panel.



5. Tilt the control box forwards by opening the holding clips located at the sides.



6. Check whether there is any water in the small hose on the automatic air vent.
7. If any leaks are detected, replace the air vent.



#### **7.4.8. Checking the safety valve**

---


1. Take out the flow collector located under the boiler.
2. Check whether there is any water in the end of the flow pipe on the safety valve.
3. If any leaks are detected, replace the safety valve.

#### **7.4.9. Checking the siphon**

---

1. Remove the siphon and clean it.
2. Fill the siphon with water.
3. Put the siphon back in place.

### 7.4.10. Checking the burner and cleaning the heat exchanger



**CAUTION**

During inspection and maintenance operations, always replace all gaskets on the parts removed.

1. Remove the air inlet flue on the venturi.
2. Unscrew the top connection on the gas valve unit.
3. Disconnect the connector located under the fan.
4. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
5. Completely remove the fan/mixing elbow unit.
6. Tilt the burner and remove it, along with the heat exchanger gasket.
7. Use a vacuum cleaner fitted with a special endpiece (accessory) to clean the top part of the heat exchanger (combustion chamber).
8. Thoroughly clean with the vacuum cleaner again without the top cleaning brush on the endpiece.
9. Check (using a mirror, for example) whether any dust can still be seen. If so, Hoover it up.
10. The burner does not require any maintenance, it is self-cleaning. Check that there are no cracks and/or other tears on the surface of the dismantled burner. If this is not the case, replace the burner.
11. Checking the ignition electrode / ionization sensor.
12. To re-assemble, perform the above actions in reverse order.



**CAUTION**

- ▶ Remember to reconnect the connector to the fan.
- ▶ Check that the gasket is correctly positioned between the mixing elbow and the heat exchanger. (Completely flat in the appropriate groove means it is leak proof).

13. Open the gas inlet valves and switch on the mains supply to the boiler.

## 7.5 Specific maintenance operations

If the standard inspection and maintenance operations have revealed the necessity to carry out additional maintenance work, proceed as follows, depending on the nature of the work:


### 7.5.1. Replacing the ionisation/ignition electrode

Replace the ionisation/ignition electrode in the following cases:

- ▶ Ionisation current  $< 3 \mu\text{A}$ .
- ▶ Electrode worn.

If replacement is necessary, proceed as follows:

1. Remove the cord from the ionisation/ignition electrode on the ignition transformer.
2. Unscrew the 2 screws and remove the ionisation/ignition electrode.
3. Replace the ionisation/ignition electrode.



### 7.5.2. Cleaning the plate exchanger (domestic hot water end) and the water filter cartridge


Depending on the water quality and the operating mode, limescale deposits may form in the plate exchanger and the water filter cartridge. Periodic descaling may therefore be necessary. As a general rule, a periodic inspection, along with cleaning, if necessary, is sufficient. The following factors may affect the periodicity:

- ▶ Water hardness.
- ▶ Composition of the limescale.
- ▶ Number of hours' operation of the boiler.
- ▶ Draw-off rate.
- ▶ Domestic hot water set point temperature.

■ **Cleaning the plate exchanger**


If descaling of the plate exchanger is necessary, proceed as follows:

1. Close the main water valve.
2. Drain the boiler.
3. Remove the air vent hose above the siphon.
4. Remove the siphon.
5. Remove the clip holding the heating flow hose in place on the left side of the hydrobloc.
6. Dismantle the heating flow hose on the left side of the hydrobloc and not on the heat exchanger side (heating circuit).
7. Unscrew the 2 hexagonal socket screws located to the right and left of the plate exchanger.
8. Slightly turn the plate exchanger and carefully remove it from the boiler.
9. Clean the plate exchanger with a descaling product (e.g. citric acid with a pH of approximately 3). To do this, a specific cleaning appliance is available as an accessory. After cleaning, rinse thoroughly under running water.
10. Re-assemble all of the components.



T001622-C

### ■ Cleaning the domestic water cartridge




If cleaning or replacement of the water filter cartridge is necessary, proceed as follows:

1. Close the main water valve.
2. Drain the boiler.
3. Remove the air vent hose above the siphon.
4. Remove the siphon.
5. Remove the clip holding the water filter cartridge in place. While doing this, be sure that the silencer is left in place.
6. Remove the domestic water cartridge.
7. Rinse the water filter cartridge with tap water and, if need be, clean it with a descaling product (e.g. citric acid with a pH of approximately 3). After cleaning, rinse thoroughly under running water.
8. Replace the water filter cartridge if faulty or when the maintenance kit includes one.
9. Re-assemble all of the components.

T001624-B

### 7.5.3. Replacing the 3-way valve



T002639-C

If it becomes necessary to replace the 3-way valve, proceed as follows:

1. Close the main water valve
2. Drain the boiler.
3. Remove the air vent hose above the siphon.
4. Remove the siphon.
5. Remove the clip holding the heating return hose in place on the right side of the hydrobloc.
6. Remove the heating return hose on the right side of the hydrobloc and not on the heat exchanger side (heating circuit).
7. Unplug the actuator.
8. Remove the clip holding the 3-way valve in place.
9. Remove the 3-way valve.

**i** Lift and rotate by a quarter turn.

10. Proceed as for dismantling in reverse.




**CAUTION**

Be careful of the positioning cams on the 3-way valve.

### 7.5.4. Replacing the non-return valve

Replace the nonreturn valve when faulty or when the maintenance kit contains one. To do this, proceed as follows:

1. Remove the air inlet flue on the venturi.
2. Unscrew the top connection on the gas valve unit.
3. Disconnect the connector located under the fan.
4. Release the 2 clips holding the fan/mixing elbow unit in place on the heat exchanger.
5. Completely remove the fan/mixing elbow unit.
6. Replace the nonreturn valve located between the mixing elbow and the fan.
7. To re-assemble, perform the above actions in reverse order.



T002517-B



### 7.5.5. Assembling the boiler



**Check  
Contrôler**

C002434-A



T001523-B

1. Follow the procedure in reverse to re-assemble all of the components.



#### CAUTION

During inspection and maintenance operations, always replace all gaskets on the parts removed.

2. Fill the siphon with clean water up to the mark.
3. Put the siphon back in place.



#### CAUTION

Mount the vent hose above the siphon.

4. Carefully open the main water valve, fill the installation, vent it and, if need be, top it up with water.
5. Check the seals on the gas and water connections.
6. Switch the boiler back on.


# 8 Troubleshooting

## 8.1 Messages (Code type Bxx or Mxx)

In the event of failure, the control panel displays a message and a corresponding code.

1. Make a note of the code displayed.  
The code is important for the correct and rapid diagnosis of the type of failure and for any technical assistance that may be needed.
2. Switch the boiler off and switch back on.  
The boiler starts up again automatically when the reason for the blocking has been removed.
3. If the code is displayed again, correct the problem by following the instructions in the table below:


Messages	Code	Description	Checking / solution
BL.PSU ERROR	B00	The PSU PCB is incorrectly configured	Parameter error on the PSU PCB ▶ Set the type of generator again in the menu <b>#CONFIGURATION</b> (Refer to the original rating plate)
BL.MAX BOILER	B01	Maximum flow temperature exceeded	The water flow in the installation is insufficient ▶ Check the circulation (direction, pump, valves)
BL.HEATING SPEED	B02	The increase in flow temperature has exceeded its maximum limit	The water flow in the installation is insufficient ▶ Check the circulation (direction, pump, valves) ▶ Check the water pressure ▶ Check the cleanliness of the heat exchanger
			Sensor error ▶ Check that the sensors are operating correctly ▶ Check whether the boiler sensor has been correctly fitted
BL.DT OUTL RET.	B07	Maximum difference between the flow and return temperature exceeded	The water flow in the installation is insufficient ▶ Check the circulation (direction, pump, valves) ▶ Check the water pressure ▶ Check the cleanliness of the heat exchanger
			Sensor error ▶ Check that the sensors are operating correctly ▶ Check whether the boiler sensor has been correctly fitted
BL.RL OPEN	B08	The RL inlet on the PCU PCB terminal block is open	Parameter error ▶ Set the type of generator again in the menu <b>#CONFIGURATION</b> (Refer to the original rating plate)
			Bad connection ▶ Check the wiring
BL.INV. L/N	B09	Set the type of generator again in the menu <b>#CONFIGURATION</b> (Refer to the original rating plate )	

Messages	Code	Description	Checking / solution
BL INPUT OPEN	B10 B11	The BL inlet on the PCU PCB terminal block is open	The contact connected to the BL inlet is open
			▶ Check the contact on the BL inlet
			Parameter error
			▶ Check the parameter <b>IN.BL</b>
			Bad connection
			▶ Check the wiring
BL. PCU COM	B13	Communication error with the SCU PCB	Bad connection
			▶ Check the wiring
			SCU PCB not installed in the boiler
			▶ Install an SCU PCB
BL.WATER MIS.	B14	The water pressure is lower than 0,8 bar	Not enough water in the circuit
			▶ Top up the installation with water
BL.GAS PRESS	B15	Gas pressure too low	Incorrect setting of the gas pressure switch on the SCU PCB
			▶ Check that the gas valve is fully opened
			▶ Checking the gas supply pressure
			▶ Check whether the gas pressure control system has been correctly fitted
			▶ Replace the gas pressure control system if need be
BL.BAD SU	B16	The SU PCB is not recognised	Wrong SU PCB for this boiler
			▶ Replace the SU PCB
BL.PCU ERROR	B17	The parameters saved on the PCU PCB are impaired	Parameter error on the PCU PCB
			▶ Replace the PCU PCB
BL.BAD PSU	B18	The PSU PCB is not recognised	Wrong PSU PCB for this boiler
			▶ Replace the PSU PCB
BL.NO CONFIG	B19	The boiler has not been configured	The PSU PCB has been changed
			▶ Set the type of generator again in the menu <b>#CONFIGURATION</b> (Refer to the original rating plate)
BL. COM SU	B21	Communication error between the PCU and SU PCBs	Bad connection
			▶ Check that the SU PCB has been correctly put in place on the PCU PCB
			▶ Replace the SU PCB
BL.FLAME LOS	B22	No flame during operation	No ionization current
			▶ Purge the gas supply to remove air
			▶ Check that the gas valve is fully opened
			▶ Check the supply pressure
			▶ Check the operation and setting of the gas valve unit
			▶ Check that the air inlet and flue gas discharge flues are not blocked
			▶ Check that there is no recirculation of flue gases
BL.SU ERROR	B25	Internal error on the SU PCB	▶ Replace the SU PCB
REVISION	M04	A service is required	The date programmed for the service has been reached
			▶ Carry out maintenance on the boiler
			▶ To clear the inspection, programme another date in the menu <b>#REVISION</b> or set the parameter <b>REVISION TYPE</b> to <b>OFF</b>
REVISION A	M05	An A, B or C service is required	The date programmed for the service has been reached
REVISION B	M06		▶ Carry out maintenance on the boiler
REVISION C	M07		▶ To clear the inspection, press key 
DISGAS	M20	A boiler vent cycle is underway	Switching the boiler on
			▶ Wait 3 minutes

Messages	Code	Description	Checking / solution
FL.DRY.B XX DAYS		Floor drying is active <b>XX DAYS</b> = Number of days' floor drying remaining.	Floor drying is underway. Heating on the circuits not concerned is shut down. <ul style="list-style-type: none"> <li>▶ Wait for the number of days shown to change to 0</li> <li>▶ Set the parameter <b>SCREED DRYING</b> to <b>OFF</b></li> </ul>
FL.DRY.C XX DAYS			
FL.DRY.B+C XX DAYS			


## 8.2 Message history


The menu **#MESSAGE HISTORIC** is used to consult the last 10 messages displayed by the control panel.

1. Access the "After Sales" level: Hold key  down until **#PARAMETERS** is displayed.
2. Select the menu **#MESSAGE HISTORIC**.




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.


 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62



3. The list of the last 10 messages is displayed.




4. Select a message to consult the information pertaining to it.




### 8.3 Faults (Code type Lxx or Dxx)



In the event of operational failure, the control panel flashes and displays an error message and a corresponding code.



C002604-A-04



C002302-D-04

1. Make a note of the code displayed.  
The code is important for the correct and rapid diagnosis of the type of failure and for any technical assistance that may be needed.
2. Press the  key. If the code is displayed again, switch off the boiler and then switch it back on.
3. Press the  key. Follow the instructions displayed to solve the problem.
4. Consult the meaning of the codes in the table below:

Faults	Code	Cause of the error	Description	Checking / solution
PSU FAIL	L00	PCU	PSU PCB not connected	Bad connection
				▶ Check the wiring between the PCU and PSU PCBs
PSU PARAM FAIL	L01	PCU	The safety parameters are incorrect	PSU PCB faulty
				▶ Replace the PSU PCB
DEF.OUTLET S.	L02	PCU	The boiler flow sensor has short-circuited	Bad connection
				▶ Check the wiring between the PCU PCB and the sensor
				▶ Check that the SU PCB is correctly in place
				▶ Check that the sensor has been correctly fitted
				Sensor fault
				▶ Check the Ohmic value of the sensor
				▶ Replace the sensor if necessary



Faults	Code	Cause of the error	Description	Checking / solution
DEF.OUTLET S.	L03	PCU	The boiler flow sensor is on an open circuit	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
DEF.OUTLET S.	L04	PCU	Boiler temp too low	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> </ul>
STB OUTLET	L05	PCU	Boiler temperature too high	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> </ul>
BACK S.FAILURE	L06	PCU	The return temperature sensor has short-circuited	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>

Faults	Code	Cause of the error	Description	Checking / solution
BACK S.FAILURE	L07	PCU	The return temperature sensor is on an open circuit	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
BACK S.FAILURE	L08	PCU	Return temperature too low	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> </ul>
STB BACK	L09	PCU	Return temperature too high	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the sensor</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> </ul>
DEP-RET<MIN	L10	PCU	Difference between the flow and return temperatures insufficient	Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				Bad connection <ul style="list-style-type: none"> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> <li>▶ Check that the heating pump is operating correctly</li> </ul>



Faults	Code	Cause of the error	Description	Checking / solution
<b>DEP-RET&gt;MAX</b>	<b>L11</b>	PCU	Difference between the flow and return temperatures too great	Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
				Bad connection <ul style="list-style-type: none"> <li>▶ Check that the sensor has been correctly fitted</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> <li>▶ Check that the heating pump is operating correctly</li> </ul>
<b>STB OPEN</b>	<b>L12</b>	PCU	Maximum boiler temperature exceeded (STB thermostat maximum)	Bad connection <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the STB</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check the electrical continuity of the STB</li> <li>▶ Check whether the STB has been correctly fitted</li> </ul>
				Sensor fault <ul style="list-style-type: none"> <li>▶ Replace the STB if necessary</li> </ul>
				No water circulation <ul style="list-style-type: none"> <li>▶ Vent the air in the heating system</li> <li>▶ Check the circulation (direction, pump, valves)</li> <li>▶ Check the water pressure</li> <li>▶ Check the cleanliness of the heat exchanger</li> </ul>
<b>BURNER FAILURE</b>	<b>L14</b>	PCU	5 burner start-up failures	Absence of ignition arch <ul style="list-style-type: none"> <li>▶ Check the wiring between the PCU PCB and the ignition transformer</li> <li>▶ Check that the SU PCB is correctly in place</li> <li>▶ Check the ionisation/ignition electrode</li> <li>▶ Check the earthing</li> <li>▶ SU PCB faulty: Change the PCB</li> </ul>
				Presence of the ignition arc but no flame formation <ul style="list-style-type: none"> <li>▶ Vent the gas flues</li> <li>▶ Check that the gas valve is fully opened</li> <li>▶ Checking the gas supply pressure</li> <li>▶ Check the operation and setting of the gas valve unit</li> <li>▶ Check that the air inlet and flue gas discharge flues are not blocked</li> <li>▶ Check the wiring on the gas valve unit</li> <li>▶ SU PCB faulty: Change the PCB</li> </ul>
				Presence of the flame but insufficient ionization (<3 µA) <ul style="list-style-type: none"> <li>▶ Check that the gas valve is fully opened</li> <li>▶ Checking the gas supply pressure</li> <li>▶ Check the ionisation/ignition electrode</li> <li>▶ Check the earthing</li> <li>▶ Check the wiring on the ionisation/ignition electrode</li> </ul>





Faults	Code	Cause of the error	Description	Checking / solution
<b>PARASIT FLAME</b>	<b>L16</b>	PCU	Detection of a parasite flame	Ionisation current present when there should not be a flame Ignition transformer defective
				▶ Check the ionisation/ignition electrode
				Gas valve defective
				▶ Check the gas valve and replace if necessary
				The burner remains very hot: CO <sub>2</sub> too high
				▶ Set the CO <sub>2</sub>
<b>VALVE FAIL</b>	<b>L17</b>	PCU	Problem on the gas valve	Bad connection
				▶ Check the wiring between the PCU PCB and the gas valve
				▶ Check that the SU PCB is correctly in place
				SU PCB faulty
				▶ Inspect the SU PCB and replace it if need be
<b>FAN FAILURE</b>	<b>L34</b>	PCU	The fan is not running at the right speed	Bad connection
				▶ Check the wiring between the PCU PCB and the fan
				Fan defective
				▶ Check for adequate draw on the chimney connection
				▶ Replace the fan if need be
<b>BACK&gt;BOIL FAIL</b>	<b>L35</b>	PCU	Flow and return reversed	Bad connection
				▶ Check that the sensor has been correctly fitted
				Sensor fault
				▶ Check the Ohmic value of the sensors
				▶ Replace the sensor if necessary
				Water circulation direction reversed
				▶ Check the circulation (direction, pump, valves)
<b>I-CURRENT FAIL</b>	<b>L36</b>	PCU	The flame went out more than 5 times in 24 hours while the burner was operating	No ionization current
				▶ Purge the gas supply to remove air
				▶ Check that the gas valve is fully opened
				▶ Checking the gas supply pressure
				▶ Check the operation and setting of the gas valve unit
				▶ Check that the air inlet and flue gas discharge flues are not blocked
				▶ Check that there is no recirculation of flue gases
<b>SU COM.FAIL</b>	<b>L37</b>	PCU	Communication failure with the SU PCB	Bad connection
				▶ Check whether the SU PCB has been correctly fitted into the connector on the PCU PCB
				▶ Change the SU PCB
<b>PCU COM.FAIL</b>	<b>L38</b>	PCU	Communication failure between the PCU and SCU PCBs	Bad connection
				▶ Check the wiring between the PCU and SCU PCBs
				▶ Run an <b>AUTODETECTION</b> in the menu <b>#CONFIGURATION</b>
				SCU PCB not connected or faulty
				▶ Replace the SCU PCB

Faults	Code	Cause of the error	Description	Checking / solution
BL OPEN FAIL	L39	PCU	The <b>BL</b> inlet opened for a short time	Bad connection
				▶ Check the wiring
				External cause
				▶ Check the device connected to the <b>BL</b> contact
				Parameter incorrectly set
				▶ Check the parameter <b>IN.BL</b>
TEST.HRU.FAIL	L40	PCU	HRU/URC unit test error	Bad connection
				▶ Check the wiring
				External cause
				▶ Suppress the external cause
				Parameter incorrectly set
				▶ Check the parameters
DEF.WATER MIS.	L250	PCU	The water pressure is too low	Hydraulic circuit incorrectly vented Water leak Measurement error
				▶ Top up with more water if necessary
				▶ Reset the boiler
MANOMETRE FAIL	L251	PCU	Pressure gauge fault	Wiring problem The manometer is defective Sensor pcb defective
				▶ Check the wiring between the PCU PCB and the pressure gauge
				▶ Check whether the pressure gauge has been correctly fitted
				▶ Replace the pressure gauge if need be
OUTL S.B FAIL. OUTL S.C FAIL.	D03 D04	SCU	Sensor fault flow circuit B Sensor fault flow circuit C  Remarks: The circuit pump is running. The 3-way valve motor on the circuit is no longer powered and can be adjusted manually.	Bad connection
				▶ Check whether the sensor is connected:  See chapter: "Deletion of sensors from the memory in the PCB", page 123
				▶ Check the link and the connectors
				▶ Check that the sensor has been correctly fitted
				Sensor fault
				▶ Check the Ohmic value of the sensor
				▶ Replace the sensor if necessary
OUTSI.S.FAIL.	D05	SCU	Fault external sensor  Remarks: The boiler operates on <b>BOILER MAX</b> temperature. The valve setting is no longer ensured but monitoring the maximum temperature of the circuit after the valve is ensured. Valves may be manually operated. Reheating the domestic hot water remains ensured.	Bad connection
				▶ Check whether the sensor is connected:  See chapter: "Deletion of sensors from the memory in the PCB", page 123
				▶ Check the link and the connectors
				▶ Check that the sensor has been correctly fitted
				Sensor fault
				▶ Check the Ohmic value of the sensor
				▶ Replace the sensor if necessary

Faults	Code	Cause of the error	Description	Checking / solution
<b>AUX.SENS.FAIL.</b>	<b>D07</b>	SCU	Auxiliary sensor failure	Bad connection <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
<b>DHW S.FAILURE</b>	<b>D09</b>	SCU	Domestic hot water sensor failure Remarks: Heating of domestic hot water is no longer ensured. The load pump operates. The load temperature of the dhw tank is the same as the boiler.	Bad connection <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
<b>ROOM S.A FAIL.</b> <b>ROOM S.B FAIL.</b> <b>ROOM S.C FAIL.</b>	<b>D11</b> <b>D12</b> <b>D13</b>	SCU	Fault room temperature sensor A Fault room temperature sensor B Fault room temperature sensor C Note: The circuit concerned operates without any influence from the room sensor.	Bad connection <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
<b>MC COM.FAIL</b>	<b>D14</b>	SCU	Communication failure between the SCU PCB and the boiler radio module	Bad connection <ul style="list-style-type: none"> <li>▶ Check the link and the connectors</li> </ul> Boiler module failure <ul style="list-style-type: none"> <li>▶ Change the boiler module</li> </ul>
<b>ST.TANK S.FAIL</b>	<b>D15</b>	SCU	Storage tank sensor failure Note: The hot water storage tank reheating operation is no longer assured.	Bad connection <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> Sensor fault <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>

Faults	Code	Cause of the error	Description	Checking / solution
SWIM.P.B. S.FAIL SWIM.P.C. S.FAIL	D16 D16	SCU	Swimming pool sensor failure circuit B Swimming pool sensor failure circuit C Note: Pool reheating is independent of its temperature.	<p>Bad connection</p> <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>▶ See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> <p>Sensor fault</p> <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
DHW 2 S.FAIL	D17	SCU	Sensor failure tank 2	<p>Bad connection</p> <ul style="list-style-type: none"> <li>▶ Check whether the sensor is connected: </li> <li>▶ See chapter: "Deletion of sensors from the memory in the PCB", page 123</li> <li>▶ Check the link and the connectors</li> <li>▶ Check that the sensor has been correctly fitted</li> </ul> <p>Sensor fault</p> <ul style="list-style-type: none"> <li>▶ Check the Ohmic value of the sensor</li> <li>▶ Replace the sensor if necessary</li> </ul>
PCU COM. FAIL	D27	SCU	Communication failure between the SCU and PCU PCBs <ul style="list-style-type: none"> <li>▶ Check the wiring between the SCU and PCU PCBs</li> <li>▶ Check that the PCU PCB is powered up (green LED on or flashing)</li> <li>▶ Change the PCU PCB</li> </ul>	
IOBL.3WV B DEF	D29	SCU	Communication failure between the SCU PCB and the V3V module	<p>The V3V module is switched off</p> <ul style="list-style-type: none"> <li>▶ Check that the 3WV module is powered up (Green LED LIT)</li> </ul> <p>The V3V module and the SCU PCB are not connected to the same live terminal</p> <ul style="list-style-type: none"> <li>▶ Check that the 3WV module and the SCU PCB are on the same live terminal or that a live coupler is installed</li> </ul> <p>The V3V module has been removed</p>
IOBL.3WV C DEF	D30	SCU	Communication failure between the SCU PCB and the V3V module	<p>The V3V module is switched off</p> <ul style="list-style-type: none"> <li>▶ Check that the 3WV module is powered up (Green LED LIT)</li> </ul> <p>The V3V module and the SCU PCB are not connected to the same live terminal</p> <ul style="list-style-type: none"> <li>▶ Check that the 3WV module and the SCU PCB are on the same live terminal or that a live coupler is installed</li> </ul> <p>The V3V module has been removed</p>
COM.IOBL FAIL.	D31	SCU	The IOBL function is no longer active	<p>Problem on the SCU PCB</p> <ul style="list-style-type: none"> <li>▶ If the IOBL function is not used, deactivate the IOBL function in the menu <b>#CONFIGURATION</b></li> <li>▶ If the IOBL function is used, change the SCU PCB and re-pair the devices (IOBL 3WV module, Interscenario switch)</li> </ul>

Faults	Code	Cause of the error	Description	Checking / solution
5 RESET:ON/OFF	D32	SCU	5 resets done in less than an hour	<ul style="list-style-type: none"> <li>▶ Switch the boiler off and switch back on</li> </ul>
TA-S SHORT-CIR	D37	SCU	The Titan Active System® is short-circuited	<ul style="list-style-type: none"> <li>▶ Check that the connection cable between the SCU PCB and the anode is not short-circuited</li> <li>▶ Check that the anode is not short-circuited</li> </ul> <p>Remarks: Domestic hot water production has stopped but can nonetheless be restarted using key .</p> <p>The tank is no longer protected. If: A tank without Titan Active System® is connected to the boiler: Check that the Titan Active System® simulation connector (delivered with package AD212) is fitted to the sensor card.</p>
TA-S DISCONN	D38	SCU	The Titan Active System® is on an open circuit	<ul style="list-style-type: none"> <li>▶ Check that the connection cable between the SCU PCB and the anode is not severed</li> <li>▶ Check that the anode is not broken</li> </ul> <p>Remarks: Domestic hot water production has stopped but can nonetheless be restarted using key .</p> <p>The tank is no longer protected. If: A tank without Titan Active System® is connected to the boiler: Check that the Titan Active System® simulation connector (delivered with package AD212) is fitted to the sensor card.</p>

### 8.3.1. Deletion of sensors from the memory in the PCB

The configuration of the sensors is memorised by the SCU PCB. If a sensor error appears whilst the corresponding sensor is not connected or has been voluntarily removed, please delete the sensor from the memory in the SCU PCB.

- ▶ Press key ? repeatedly until **"Do you want to delete this sensor?"** is displayed.
- ▶ Select **YES** by turning the rotary button and press to confirm.

### 8.3.2. Deleting the IOBL 3WV modules from the memory in the PCB

The configuration of the IOBL 3WV modules is memorised by the SCU PCB. If a **IOBL.3WV B DEF** or **IOBL.3WV C DEF** error appears after voluntary deletion of a 3WV module, please delete the module from the memory in the SCU PCB.

- ▶ Press key ? repeatedly until **"Do you want to delete this module?"** is displayed.
- ▶ Select **YES** by turning the rotary button and press to confirm.



You have the option of removing a IOBL 3WV module from the memory in the SCU PCB:

- ▶ Go to the menu **#NETWORK** and select **REMOVE DEVICE**.

## 8.4 Failure history


The menu **#DEFAULT HISTORIC** is used to consult the last 10 errors displayed by the control panel.

1. Access the "After Sales" level: Hold key down until **#PARAMETERS** is displayed.
2. Select the menu **#DEFAULT HISTORIC**.




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.


For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62



C002272-C-04



C002274-D-04




C002275-B-04

3. The list of the last 10 errors is displayed.

4. Select an error to consult the information pertaining to it.


## 8.5 Parameter and input/output check (mode tests)


Use the following menus to target the cause of a malfunction.

1. Access the "After Sales" level: Hold key  down until **#PARAMETERS** is displayed.
2. Check the following parameters:




- ▶ Turn the rotary button to scroll through the menus or modify a value.
- ▶ Press the rotary button to access the menu selected or confirm a value modification.

 For a detailed explanation of menu browsing, refer to the chapter: "Browsing in the menus", page 62



C002272-C-04

"After Sales" level - #PARAMETERS menu	
Parameter	Description
PERMUT	Master boiler active
STAGE	Number of boilers requesting heating
NB.CASC.:	Number of boilers recognised in the cascade
NB. VM:	Number of DIEMATIC VM control systems recognised in the cascade
POWER %	Current output of the boiler
PERCENT PUMP	Modulating pump command
SPEED FAN <sup>(1)</sup>	Fan rotation speed
SETPPOINT FAN	Fan rotation speed desired
MEAN OUTSIDE T	Average outside temperature
CALC.T. BOILER	Temperature calculated by the boiler
BOILER. T. <sup>(1)</sup>	Measurement of the boiler flow sensor
CALCULATED T. A	Calculated temperature for circuit A
CALCULATED T. B <sup>(2)</sup>	Calculated temperature for circuit B
CALCULATED T. C <sup>(2)</sup>	Calculated temperature for circuit C
OUTLET TEMP. B <sup>(1)</sup> <sup>(2)</sup>	Temperature of the flow water in circuit B
OUTLET TEMP. C <sup>(1)</sup> <sup>(2)</sup>	Temperature of the flow water in circuit C
OUTSIDE TEMP. <sup>(1)</sup>	Outside temperature
ROOMTEMP. A <sup>(1)</sup>	Room temperature of circuit A
ROOMTEMP. B <sup>(1) (2)</sup>	Room temperature of circuit B
ROOMTEMP. C <sup>(1) (2)</sup>	Room temperature of circuit C
WATER TEMP. <sup>(1)(2)</sup>	Water temperature in the DHW tank
IN 0-10V <sup>(1)(2)</sup>	Voltage at input 0-10 V
BACK TEMP <sup>(1)</sup>	Temperature of the boiler return water
CURRENT <sup>(1)</sup>	Ionization current
PRESSURE <sup>(1)</sup>	Water pressure in the installation
STOR.TANK.TEMP <sup>(1)</sup> <sup>(2)</sup>	Water temperature in the storage tank

<sup>(1)</sup> The parameter can be displayed by pressing key .

<sup>(2)</sup> The parameter is only displayed for the options, circuits or sensors actually connected


"After Sales" level - #PARAMETERS menu	
Parameter	Description
SYSTEM TEMP. (1)(2)	Temperature of the system flow water if multi-generator
T.DHW BOTTOM (1)(2)	Water temperature in the bottom of the DHW tank
DHW A TEMP. (1)(2)	Water temperature in the second DHW tank connected to circuit A
TEMP.TANK AUX (1)(2)	Water temperature in the second DHW tank connected to the AUX circuit
KNOB A	Position of temperature setting button on room sensor A
KNOB B (2)	Position of temperature setting button on room sensor B
KNOB C (2)	Position of temperature setting button on room sensor C
OFFSET ADAP A	Parallel trigger calculated for circuit A
OFFSET ADAP B (2)	Parallel trigger calculated for circuit B
OFFSET ADAP C (2)	Parallel trigger calculated for circuit C

(1) The parameter can be displayed by pressing key  $\mu$ A.

(2) The parameter is only displayed for the options, circuits or sensors actually connected

"After Sales" level - #TEST OUTPUTS menu		
Parameter	Adjustment range	Description
P. CIRC. A	ON / NO	Stop/start pump circuit A
P. CIRC. B (1)	ON / NO	Stop/start pump circuit B
P. CIRC. C (1)	ON / NO	Stop/start pump circuit C
HW. PUMP (1)	ON / NO	Stop/start domestic hot water pump
AUX.CIRC.	ON / NO	On/Off auxiliary outlet
3WV B (1)	REST	No command
	OPEN:	Opening 3-way valve circuit B
	CLOSE:	Closure 3-way valve circuit B
3WV C (1)	REST	No command
	OPEN:	Opening 3-way valve circuit C
	CLOSE:	Closure 3-way valve circuit C
TEL.OUTPUT	ON / NO	On/Off telephone relay outlet

(1) The parameter is only displayed for the options, circuits or sensors actually connected

"After Sales" level - #TEST INPUTS menu		
Parameter	Status OK	Description
PHONE REM.		Bridge on telephone input (1 = presence, 0 = absence)
FLAME		Flame presence test (1 = presence, 0 = absence)
VALVE	OP/CL	Opening the valve Closing the valve
FAILURE	ON	Error display
	OFF	No error
SEQ.		Control system sequence.  See table below.
BOILER		Index of the generator in the system
TYPE		Generator type
VER.ROM		Version of the PCU PCB programme
VERS.PARAM PCU		Version of the PCU PCB parameters
MC.VERSION (1)		Version of the boiler radio module programme
OUTSI.S.VERSION (1)		Version of the radio outside temperature sensor programme


(1) The parameter is only displayed for the options, circuits or sensors actually connected



"After Sales" level - #TEST INPUTS menu		
Parameter	Status OK	Description
R.CTRL A <sup>(1)</sup>	ON	Presence of a remote control A
	OFF	No remote control A
R.CTRL B <sup>(1)</sup>	ON	Presence of a remote control B
	OFF	No remote control B
R.CTRL C <sup>(1)</sup>	ON	Presence of a remote control C
	OFF	No remote control C
ID MC IOBL		Identifying number of the IOBL boiler module
IOBL.VERSION		IOBL version of the SCU PCB
CALIBRA.CLOCK		Clock calibration
(1) The parameter is only displayed for the options, circuits or sensors actually connected		

"After Sales" level - #CONFIGURATION menu		
Parameter	Adjustment range	Description
MODE:	MONO/ ALL.CIRC.	To chose if the exemption made for one remote control applies to a single circuit ( <b>MONO</b> ) or if it must be transmitted to a group of circuits ( <b>ALL CIRC</b> )
TYPE		Generator type (Refer to the original rating plate)
AUTODETECTION	OFF/ON	System reset if error <b>L38</b> is displayed
TAS	OFF/ON	Activation of the Titan Active System® function
IOBL	OFF/ON	Activation of the IOBL function

Control system sequence		
Status OK	Sub-status	Operation
0	0	Boiler stopped
1	1	Anti-short cycle activated
	2	Open isolating valve
	3	Start-up of the boiler pump
	4	Awaiting burner start-up
2	10	Open gas valve (external)
	11	Fan start-up
	13	The fan switches to the burner start-up speed
	14	Check RL signal (Function not active)
	15	Burner on switch request
	17	Pre-ignition
	18	Ignition
	19	Check flame presence
	20	Awaiting further action to unsuccessful ignition

Control system sequence		
Status OK	Sub-status	Operation
3 / 4	30	Burner lit and free modulation on the boiler instruction
	31	Burner lit and free modulation on a limited instruction, equal to a return temperature of +30°C
	32	Burner lit and free modulation on the boiler set point but restricted on the control panel  See menu #PRIMARY LIMITS: ""Professional" settings", page 82
	33	Burner lit and descending modulation following too large a rise in temperature on the exchanger (4 K in 10 seconds)
	34	Burner lit and minimum modulation following too large a rise in temperature on the exchanger (7 K in 10 seconds)
	35	Burner off following too large a rise in temperature on the exchanger (9 K in 10 seconds)
	36	Burner lit and ascending modulation to guarantee a correct ionization current
	37	Heating: Burner lit and minimum modulation after a burner start-up lasting 30 seconds DHW production: Burner lit and minimum modulation after a burner start-up lasting 100 seconds
	38	Burner lit and modulation fixed higher than the minimum after burner start-up lasting 30 seconds, if the burner was off for more than 2 hours or after powering up
5	40	The burner will stop
	41	The fan switches to post-sweeping speed on the burner
	42	The external gas valve closes
	43	Post-sweeping
	44	Stop fan
6	60	Post-operation of the boiler pump
	61	Stop boiler pump
	62	Close isolating valve
	63	Start anti short cycle
8	0	Awaiting burner start-up
	1	Anti-short cycle activated
9	--	Blockage detected
10	--	Lock-out
16	--	Bleed
17	--	Antifreeze protection

# 9 Spare parts

---

## 9.1 General

---

When it is observed subsequent to inspection or maintenance work that a component in the boiler needs to be replaced, use only original spare parts or recommended spare parts and equipment.



To order a spare part, give the reference number shown on the list.


## 9.2 Spare parts

---

Spare parts list reference: 300022146-002-A


### 9.2.1. Casing

1




### 9.2.2. Heat exchanger and burner

2




### 9.2.3. Fan

3




### 9.2.4. Control panel

4



### 9.2.5. Connecting pipes (MCA 15 - MCA 25)


5





### 9.2.6. Connecting pipes (MCA 25/28 MI)

5



### 9.2.7. Spare parts list

Markers	Code no.	Description	Part
<b>Casing</b>			
1001	S100938	Front panel	1
1002	S100940	Control panel flap	1
1006	S101403	Screw	2
<b>Heat exchanger and burner</b>			
2001	S100893	Heating body - 28 kW	1
2002	S100894	Condensates collector - 253 mm	1
2003	S100703	Pump Grundfos UPM 15-70 RES	1
2004	S100905	Siphon	1
2005	S100909	Flow and return pipes	1
2006	S100854	Flue gas discharge pipe - Ø 80 mm (28 kW)	1
2007	S100906	Siphon gasket	5
2009	S100815	76x4 O-ring	5
2010	S59597	18x2,8 O-ring	10
2011	S101003	NTC temperature sensor	2
2012	S100890	Ignition electrode	1
2013	S59118	Indicator	1
2014	S62105	Electrode gasket	10
2015	S48950	Screw M4x10	50
2016	S100880	Gasket for burner - 212x84	1
2017	S101178	Air vent key	2
2017	97920027	Automatic air vent	1
2018	S100895	Endpiece - M7x1	1
2019	S100891	Silicone hose 8x4x715	1
2020	S100888	Gasket between heat exchanger and condensate collector 219 mm	1
2021	S100892	Gasket between flue gas discharge and condensate collector	1
2022	S100855	Leak proofing ring - Ø 80 mm	5
2023	S100850	Plug for the flue gas measuring point	1
2024	S100901	Plate exchanger holding plate	1
2025	S100848	Holding clip for the flue gas discharge pipe	2
2026	S62768	Flue gas discharge pipe	1
2028	S62232	Plug for the flue gas measuring point	5
2029	S62233	Plug for the flue gas measuring point	5
2030	S59141	Screw M5x18	15
2032	S59586	Clip - 18 mm	10
2033	S100838	Ignition transformer	1
2034	S100954	Clamp	10
2036	S100925	Expansion vessel	1
2037	S100908	Pipe between the pump and the opened expansion vessel	1
2038	S44483	Nuts M8	10
2039	S101007	Serrated washer 8,2	4
2050	S101005	HL temperature sensor	1
<b>Fan</b>			
0	S101541	Propane diaphragm - 3.00 mm	1
0	S101542	Propane diaphragm - 4.00 mm	1
3001	S101507	Gas block	1
3002	S100886	Fan RG118 - R14,2x1 (MCA 15 - MCA 25)	1

Markers	Code no.	Description	Part
3003	S100879	Burner 198 mm - 28 kW	1
3004	S100881	Gasket 83 mm with 28 kW valve	1
3005	S100882	Gas/air mixer 220x84 mm	1
3006	S100910	Gas inlet pipe	1
3007	S100911	Silencer	1
3008	S56155	Gasket - Ø 23,8x17,2x2 mm	20
3010	S100806	Connection part 15 mm	1
3011	S100951	Screw M5x25	10
3012	S101010	Nuts G3/4	10
<b>Control panel</b>			
0	S101253	Indicator	1
0	S100856	Card PSU	1
0	95362450	Exterior sensor AF60 (MCA 15 - MCA 25)	1
4001	S101478	PCU PCB	1
4002	S100849	SU PCB	1
4003	S101249	Display plate	1
4004	S6778	6.30 glass fuse A slow	10
4004	S43562	3.15 glass fuse A slow	10
4006	S100821	Pressure sensor	1
4007	S100838	Ignition transformer with ignition electrode	1
4008	S101003	NTC temperature sensor	1
4009	S100842	3-way valve cable	1
4010	S59372	Draught diverter	1
4011	S100861	Oval sealing gasket	5
4012	S62185	Screw KB 30x8	10
4014	S101251	Control panel	1
4015	S48950	Screw M4x10	50
4016	S101005	HL temperature sensor	1
4017	S100862	SCU grommet	5
4018	S101000	Grommet	5
4021	S101048	SCU PCB	1
4022	S100860	SCU box	1
4023	S100843	SCU 230 V cable	1
4024	S100847	SCU cable	1
4025	S100846	Pump cable	1
4026	S100840	Sensor cable	1
4027	S100845	Cable 1500 mm	1
4028	S100844	Gas valve and transformer cable	1
<b>Connecting pipes</b>			
0	S14254	Self-tapping screw 4,2x9,5	20
0	S62185	Screw K30x8	10
5002	S100823	adapter with 3-way valve	1
5004	S100822	Right hand hydrobloc + actuator + pressure sensor	1
5006	S100828	Left hand hydrobloc	1
5007	S100824	Cartridge body	1
5008	S100829	Safety valve	1
5010	S100821	Pressure sensor	1
5011	S100815	76x4 O-ring	5
5012	S59597	18x2,8 O-ring	10
5013	S59586	Clip - 18 mm	10
5014	S100873	Hose holding clip	5

Markers	Code no.	Description	Part
5015	S100835	Clip - 16 mm	10
5016	S100810	25,2x17 O-ring	20
5017	S100813	Clip 26	20
5018	S100816	22,2x2,5 O-ring	20
5019	S100826	Screw K50x28 (MCA 15 - MCA 25)	10
5022	S100814	Clip 10,3	5
5023	S100832	Clip 26 with handle	10
5025	S59141	Screw M5x18	15
5027	S101002	Condensates discharge	1
5028	S100866	Pipe for safety valve	1
5029	S100825	Screw K50x12	20
5030	S62727	Grommet - Ø 20 mm	15
5031	S100809	Flow and return connection 18 mm	1
5032	S100808	Connection part 13 mm	1
5033	S100827	Connection for hydrobloc 2S (MCA 15 - MCA 25)	1
5037	S101046	Attachment clip (Kit)	1
5038	S100875	Valve G3/4" disconnecter	1
5039	S100871	DHW valve 1/2"	1
5042	S100876	Pressure gauge	1
5043	S100231	M10x1x5 nut	10
5044	S101193	Disconnecter	1
5045	S101011	Pipe kit	1
5046	S100937	Mounting frame	1
5047	86665557	Disconnecter	1
5048	S101195	Union nut 3/8"x12	2
5049	S62715	Seal ø 14.5x8.5x2	10
5050	S100238	Condensates collector	1
5052	S56157	Seal ø 18.3x12.7x2	10
5053	S56155	Seal ø 23.8x17.2x2	20







**DE DIETRICH THERMIQUE S.A.S.**[www.dedietrich-thermique.fr](http://www.dedietrich-thermique.fr)

Direction des Ventes France  
57, rue de la Gare  
F- 67580 MERTZWILLER  
☎ +33 (0)3 88 80 27 00  
✉ +33 (0)3 88 80 27 99

**ÖAG AG**[www.o eag.at](http://www.o eag.at)

Schemmelrstrasse 66-70  
A-1110 WIEN  
☎ +43 (0)50406 - 61624  
✉ +43 (0)50406 - 61569  
dedietrich@o eag.at

**DE DIETRICH REMEHA GmbH**[www.dedietrich-remeha.de](http://www.dedietrich-remeha.de)

Rheiner Strasse 151  
D- 48282 EMSDETTEN  
☎ +49 (0)25 72 / 23-5  
✉ +49 (0)25 72 / 23-102  
info@dedietrich.de

**NEUBERG S.A.**[www.dedietrich-heating.com](http://www.dedietrich-heating.com)

39 rue Jacques Stas  
L- 2010 LUXEMBOURG  
☎ +352 (0)2 401 401

**VAN MARCKE**[www.vanmarcke.be](http://www.vanmarcke.be)

Weggevoerdenlaan 5  
B- 8500 KORTRIJK  
☎ +32 (0)56/23 75 11

**DE DIETRICH**[www.dedietrich-otoplenie.ru](http://www.dedietrich-otoplenie.ru)

129090 г. Москва  
ул. Гиляровского, д. 8  
офис 52  
☎ +7 495 988-43-04  
✉ +7 495 988-43-04  
dedietrich@nnt.ru

**WALTER MEIER (Klima Schweiz) AG**[www.waltermeier.com](http://www.waltermeier.com)

Bahnstrasse 24  
CH-8603 SCHWERZENBACH  
☎ +41 (0) 44 806 44 24  
Serviceline +41 (0)8 00 846 846  
✉ +41 (0) 44 806 44 25  
ch.klima@waltermeier.com

**WALTER MEIER (Climat Suisse) SA**[www.waltermeier.com](http://www.waltermeier.com)

Z.I. de la Veyre B, St-Légier  
CH-1800 VEVEY 1  
☎ +41 (0) 21 943 02 22  
Serviceline +41 (0)8 00 846 846  
✉ +41 (0) 21 943 02 33  
ch.climat@waltermeier.com

**DE DIETRICH**[www.dedietrich-heating.com](http://www.dedietrich-heating.com)

Room 512, Tower A, Kelun Building  
12A Guanghua Rd, Chaoyang District  
C-100020 BEIJING  
☎ +86 (0)106.581.4017  
+86 (0)106.581.4018  
+86 (0)106.581.7056  
✉ +86 (0)106.581.4019  
contactBJ@dedietrich.com.cn



T000249-B



AD001-AC

© Copyright

All technical and technological information contained in these technical instructions, as well as any drawings and technical descriptions supplied, remain our property and shall not be multiplied without our prior consent in writing.

29/04/2010



300022146-001-B

**De Dietrich**

DE DIETRICH THERMIQUE

57, rue de la Gare F- 67580 MERTZWILLER - BP 30