BOILER OPTIONS

OTHER ACCESSORIES




HWPlus 70 decoupling cylinder - Package HC 28

For all installations with 2 circuits (1 direct circuit + 1 valve circuit) or for installations in cascade up to 70kW is the use of decoupling cylinder highly recommended. The HWPlus 70 cylinder is delivered

with 1 manual air vent and 1 drainage valve. It can be pivoted on itself for connection to the left or right of the boiler. He is delivered insulated and fitted with a bracket to secure it to the wall.



Cleaning tool boiler body - Package HR 45 Connects to a classic vacuum cleaner and allows an easy boiler body cleaning.



Condensates neutralisation system with pump - Package DU 13 Condensates neutralisation system without pump - Package BP 52 Neutralisation granules (10kg) Ref. 94225601



Condensate neutralisation tank - Package HC 33
Wall bracket for neutralisation tank - Package HC 34
Granule refill for neutralisation tank (2kg) - Package HC 35

The materials used for the condensates flow pipes must be appropriate; otherwise the condensates must be neutralised.

Principle: The acidic condensates flow through a tank filled with granules before being discharged into the waste water network.



Flue gas thermostat - Package JA 38 This thermostat cut the boiler when the flue gas temperature exceeds 110°C.

Propane conversion kit for AGC 15..., / V..., /B... - Package JA 39 Propane conversion kit for AGC 25..., / V..., /B... - Package JA 40 Propane conversion kit for AGC 35..., / V..., /B... - Package JA 41

BOILER OPTIONS

Stove fitting accessories specific to boilers AGC



Adapter Ø 80/125mm - Package HR 38 Is fitted instead and in place of the Ø 60/100mm fitting deliverred mounted on the boiler. It enables the direct connection of a vertical forced flue

 \varnothing 80/125mm or a boiler connection kit if connected to the collective flue system duct.




Adapter bi-flow Ø 60/100mm to 2 x Ø 80mm - Package DY 868



Reducing elbow - Package JA 43

When, for reasons of space, the horizontal forced flue with its elbow cannot be installed, this elbow is mounted instead and in place of the fitting (\varnothing 60/100mm) on the boiler and thus allows a height saving of 70 mm.



Connecting kit Ø 80/125mm on collective flue system duct - Package DY 887

If connected to a collective flue system duct, the adapter Ø 60/100mm delivered with the boiler should be removed and replaced by

package DY 887, wich incorporates the adapter \varnothing 80/125mm.

For DHW production



Domestic hot water sensor - Package AD 212

This is used for regulating the DHW temperature as a priority and programming of domestic hot water

production with an independent calorifier.



Magnesium anode kit for tank protection - Package EA 103

For DHW calorifier models AGC.../V... and AGC.../B..., if the "Titan Active System®" self-adapting current anode fitted as standard is not

permanently activated (in secondary homes, for example).




Kit DHW expansion vessel for AGC.../V 100 HL and /V 160 SL - Package ER 233

Can be integrated in the boiler, prevents water loss during tank reheating in DHW mode.



Recirculation kit for calorifier 100 HL - Package ER 218



Recirculation kit for calorifiers 160 SL and 220 SHL - Package ER 219



Connecting kit for the connection of a independent calorifer - Package JA 10

For AGC... (heating only), this kit mounted under the casing of the boiler allows the connection of a independent calorifier.